California Proposition 65 Warning

A WARNING

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

This manual should be considered a permanent part of the motorcycle and should remain with the motorcycle when resold or otherwise transferred to a new owner or operator. The manual contains important safety information and instructions which should be read carefully before operating the motorcycle.

IMPORTANT

▲ WARNING/▲ CAUTION/ NOTICE/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol & and the words WARNING, CAUTION, NOTICE and NOTE have special meanings. Pay particular attention to messages highlighted by these signal words:

WARNING

Indicates a potential hazard that could result in death or serious injury.

A CAUTION

Indicates a potential hazard that could result in minor or moderate injury.

NOTICE

Indicates a potential hazard that could result in vehicle or equipment damage.

NOTE: Indicates special information to make maintenance easier or instructions clearer.

FOREWORD

Motorcycling is one of the most exhilarating sports and to ensure your riding enjoyment, you should become thoroughly familiar with the information presented in this Owner's Manual before riding the motorcycle.

The proper care and maintenance that your motorcycle requires is outlined in this manual. By following these instructions explicitly, you will ensure a long trouble-free operating life for your motorcycle. This motorcycle also conforms to the U.S. Environmental Protection Agency (EPA) and California Air Resource Board (CARB) emission regulations which apply to new motorcycles. The proper adjustment of engine components is necessary for this motorcycle to comply with the EPA and CARB regulations. Therefore, please follow the maintenance instructions closely to ensure emission compliance. Your Suzuki dealer has experienced technicians that are trained to provide your machine with the best possible service with the right tools and equipment.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. Due to improvements or other changes, there may be some discrepancies between information in this manual and your motorcycle. Suzuki reserves the right to make production changes at any time, without notice and without incurring any obligation to make the same or similar changes to vehicles previously built or sold.

Suzuki Corporation Motor believes in conservation and protection of Earth's natural resources. To that end. encourage every vehicle owner to recycle, trade in, or properly dispose of, as appropriate, used motor oil, coolant, and other fluids, batteries and tires.



TABLE OF CONTENTS

.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
THE SPORT OF MOTORCYCLING	1
FUEL, ENGINE OIL AND COOLANT RECOMMENDATIONS	2
CONTROLS, EQUIPMENT AND ADJUSTMENTS	3
BREAK-IN AND INSPECTION BEFORE RIDING	4
RIDING TIPS	5
ACCESSORY USE AND MOTORCYCLE LOADING	6
INSPECTION AND MAINTENANCE	7
TROUBLESHOOTING	8
STORAGE PROCEDURE AND MOTORCYCLE CLEANING	9
CONSUMER INFORMATION	10
SPECIFICATIONS	
INDEX	

THE SPORT OF MOTORCYCLING

MOST ACCIDENTS CAN BE AVOIDED	1-2
IF YOU DON'T HAVE A HELMET, BUY A HELMET AND	
WEAR IT EVERY TIME YOU RIDE	1-3
IF A COLLISION IS IMMINENT, DO SOMETHING	1-3
SPECIAL SITUATIONS REQUIRE SPECIAL CARE	1-4
KNOW YOUR LIMITS	1-5
BE EXTRA SAFETY-CONSCIOUS ON BAD WEATHER DAYS	1-5
PRACTICE AWAY FROM TRAFFIC	1-5
INSPECTION BEFORE RIDING	
ACCESSORIES AND LOADING	1-6
CARRYING A PASSENGER	1-6
MOTORCYCLE SAFETY FOUNDATION'S	
"RIDING TIPS AND PRACTICE GUIDE" HANDBOOK	
(FOR OWNERS IN USA)	1-7
BE STREET SMART	
LABELS	1-7
CONCLUSION	1-7

THE SPORT OF MOTORCYCLING

Your motorcycle and this owner's manual have been designed by people like you who enjoy motorcycling. People become motorcyclists for many reasons. For starters, street riding is fun and invigorating. But no matter why you became a motorcyclist, or how experienced you are, you will eventually face some challenging situations.

In preparing for these challenges, you will be fine-tuning your coordination, concentration, and attitude. Learning the skills and strategies associated with motorcycling is the basis for safely participating in this sport. Many motorcyclists find that as they become better riders, they also get more enjoyment from the freedom unique to motorcycling.

Please remember:

MOST ACCIDENTS CAN BE AVOIDED

The most common type of motorcycle accident in the U.S. occurs when a car traveling towards a motorcycle turns left in front of the motorcycle. Is that because other drivers are out to get motorcyclists? No. Other drivers simply don't always notice motorcyclists.

Ride defensively. Wise motorcyclists use a strategy of assuming they are invisible to other drivers, even in broad daylight. Pay careful attention to other motorists, especially at intersections, because they may not be paying attention to you. Select a lane position that gives you the best view of others, and other motorists the best view of you. Wear bright, reflective clothing. Put reflective strips on your helmet.

IF YOU DON'T HAVE A HELMET, BUY A HELMET AND WEAR IT EVERY TIME YOU RIDE

Most accidents occur within a few miles of home, and almost half occur at speeds of less than 30 mph. So even if you're just going on a quick errand, be prepared—strap on your helmet before you take off.

Helmets do not reduce essential vision or hearing. Generally, helmets do not cause or intensify injury if you crash. Helmets simply help your skull protect your intelligence, your memory, your personality, and your life.

Your eyesight is equally valuable. Wearing suitable eye protection can help keep your vision unblurred by the wind and save your eyes from airborne hazards like bugs, dirt, or pebbles kicked up by tires.

IF A COLLISION IS IMMINENT, DO SOMETHING

Many riders fear locking up their brakes or haven't learned to swerve to avoid an accident. Many inexperienced riders (and too many seasoned riders) use only their rear brake in an emergency, resulting in unnecessary impacts in some cases unnecessarily high impact speeds in other cases. Your rear brake can only provide about 30% of your motorcycle's potential stopping power. The front and rear brakes can and should be used together to maximize braking effectiveness.

Experienced motorcyclists learn to "cover" the front brake lever by lightly resting a couple of fingers over the lever when riding in traffic and near intersections to give their reaction time a head start.

Emergency stopping and swerving are techniques that should practice and master before you find yourself in an emergency situation. The best place to practice such techniques is in a controlled environment such as the Motorcycle Safety Foundation's (MSF) rider training courses. The MSF's Motorcycle Rider Courses (fundamental techniques) and Experienced Rider Courses (advanced strategies) present hands-on instruction of the basic principles of motorcycling and a accident-avoidance variety of maneuvers. Even a seasoned motorcyclist can improved his or her riding skills, and pick up a few new skills, through these courses. Some insurance companies even offer discounts to course graduates.

SPECIAL SITUATIONS REQUIRE SPECIAL CARE

Of course, there are some times when full-force braking is not the correct technique. When the road surface is wet, loose, or rough, you should brake with care. When you're leaned over in a corner, avoid braking. Straighten up before braking. Better yet, slow down before entering the corner.

In these situations, the traction available between your tires and the road surface is limited. Overbraking when traction is limited will cause your tires to skid, possibly resulting in loss of directional control or causing you and your motorcycle to fall over.

KNOW YOUR LIMITS

Always ride within the boundaries of your own skills. Knowing these limits and staying within them will help you avoid accidents.

A major cause of accidents involving only a motorcycle (and no cars) is going too fast through a turn. Before entering a turn, select an appropriately low cornering speed.

Even on straight roads, ride at a speed that is appropriate for the traffic, visibility and road conditions, your motorcycle, and your experience.

motorcycle safely Riding а requires that your mental and physical skills are fully part of the experience. should You not attempt to operate a motor vehiespecially one with cle, two wheels, if you are tired or under the influence of alcohol or other drugs. Alcohol, illegal drugs, and even some prescription and overthe-counter drugs can cause drowsiness, loss of coordination, loss of balance, and especially the loss of good judgment. If you are tired or under the influence of alcohol or other drugs, PLEASE DO NOT RIDE your motorcycle.

BE EXTRA SAFETY-CONSCIOUS ON BAD WEATHER DAYS

Riding on bad weather days, especially wet ones, requires extra caution. Braking distances increase on a rainy day. Stay off the painted surface marks, manhole covers, and greasy-appearareas, as they can ing especially slippery. Use extra caution at railway crossings and on metal gratings and bridges. When it starts to rain, any oil or grease on the road rises to the surface of the water. Pull over and wait a few minutes until this oil film is washed before awav Whenever in doubt about road conditions, slow down!

PRACTICE AWAY FROM TRAFFIC

Your riding skill and your mechanical knowledge form the foundation for safe riding practices. We suggest that you practice riding your motorcycle in a non-traffic situation until you are thoroughly familiar with your machine and its controls. Again, consider taking one of the MSF's Rider Courses. Even experts will be pleased with the caliber of the information presented in these courses. As the MSF says: "The more you know, the better it gets!"

INSPECTION BEFORE RIDING

Review the instructions in the "INSPECTION BEFORE RIDING" section of this manual. Perform an entire pre-ride inspection before you head out on the road. Spending a few minutes preparing your machine for a ride can help prevent accidents due to mechanical failure or costly, inconvenient breakdowns far from home.

ACCESSORIES AND LOADING

The accessories you use with your motorcycle and the manner in which you load your gear onto the bike might create hazards. Aerodynamics, handling, balance, and cornering clearance can suffer, and the suspension and tires can be overloaded. Read the "ACCESSORY USE AND MOTORCYCLE LOADING" section.

CARRYING A PASSENGER

Carrying a passenger, when done correctly, is a great way to share the joy of motorcycling. You will have to alter your riding style somewhat since the extra weight of a passenger will affect handling and braking. You may also need to adjust tire pressures and suspension; please refer to the Tire Pressure and Loading section and the Suspension section for more details.

A passenger needs the same protection that you do, including a helmet and proper clothing. The passenger should not wear long shoe laces or loose pants that could get caught in the wheel or the chain. Passengers must be tall enough that their feet reach the footrests.

MOTORCYCLE SAFETY FOUNDATION'S "RIDING TIPS AND PRACTICE GUIDE" HANDBOOK (FOR OWNERS IN USA)

This special handbook, supplied with your owner's manual, contains a variety of safety tips, helpful hints, and practice exercises. This manual can increase your riding enjoyment and safety. You should read it thoroughly.

BE STREET SMART

Always heed speed limits, local laws, and the basic rules of the road. Set a good example for others by demonstrating a courteous attitude and a responsible riding style.

LABELS

Read and follow all the labels on the motorcycle. Make sure you understand all of the labels. Do not remove any labels from the motorcycle.

CONCLUSION

Traffic, road and weather conditions vary. Other motorists' actions are unpredictable. Your motorcycle's condition can change. These factors can best be dealt with by giving every ride your full attention.

Circumstances beyond your control could lead to an accident. You need to prepare for the unexpected by wearing a helmet and other protective gear, and learning emergency braking and swerving techniques to minimize the damage to you and your machine.

The best way to learn basic riding skills and evasive maneuvers or refresh your own riding skills is to take one of the courses offered by the Motorcycle Safety Foundation. Your Suzuki dealer can help you locate the fundamental or advanced riding skills course nearest you, or owners in the USA can call toll-free 1-800-446-9227.

Good riding on your new Suzuki!



FUEL, ENGINE OIL AND COOLANT RECOMMENDATIONS

FUEL	2-2
ENGINE OIL	2-4
ENGINE COOLANT SOLUTION	2-5

FUEL, ENGINE OIL AND COOLANT RECOMMENDATIONS

FUEL

Your motorcycle requires premium unleaded gasoline with a minimum pump octane rating of 90 ((R+M)/2 method). In some areas, the only fuels that are available are oxygenated fuels.

NOTE:

- The GSX1300RA engine is designed to use premium unleaded gasoline only. Use premium unleaded gasoline under all riding conditions.
- If the engine develops some trouble like lack of acceleration or insufficient power, the cause may be due to the fuel the motorcycle uses. In such case, try changing to a different gas station. If the situation is not improved by changing, consult your Suzuki dealer.

Oxygenated fuels which meet the minimum octane requirement and the requirements described below may be used in your motorcycle without jeopardizing the New Vehicle Limited Warranty or the Emission Control System Warranty.

NOTE: Oxygenated fuels are fuels which contain oxygen-carrying additives such as alcohol.

Gasoline/Ethanol Blends

Blends of unleaded gasoline and ethanol (grain alcohol), also known as GASOHOL, are commercially available in some areas. Blends of this type may be used in your motorcycle if they are no more than 10% ethanol. Make sure this gasoline-ethanol blend has octane ratings no lower than those recommended for gasoline.

Use the recommended gasoline which conforms to the following labels.



Fuel Pump Labeling

In some states, pumps that disoxygenated fuels are pense required to be labeled for the type and percentage of oxygenate, and whether important additives are present. Such labels may provide enough information for you to determine if a particular blend of fuel meets the requirements listed above. In other states, pumps may not be clearly labeled as to the content or type of oxygenate and additives. If you are not sure that the fuel you intend to use meets these requirements, check with the service station operator or the fuel supplier.

NOTE:

- To help minimize air pollution, Suzuki recommends that you use oxygenated fuels.
- Be sure that any oxygenated fuel you use has octane ratings of at least 90 pump octane ((R+M)/2 method).
- If you are not satisfied with the drivability of your motorcycle when you are using an oxygenated fuel, or if engine pinging is experienced, substitute another brand as there are differences between brands.

NOTICE

Spilled gasoline containing alcohol can damage the painted surfaces of your motorcycle.

Be careful not to spill any fuel when filling the fuel tank. Wipe spilled gasoline up immediately.

ENGINE OIL

Suzuki recommends the use of SUZUKI PERFORMANCE 4 MOTOR OIL or equivalent engine oil. If SUZUKI PERFORMANCE 4 MOTOR OIL is not available, select a proper engine oil according to the following guideline.

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil. Use oil with an API (American Petroleum Institute) classification of SG, SH, SJ, SL, SM or SN with a JASO classification of MA.


SAE	API	JASO
10W-40	SG, SH, SJ, SL, SM or SN	MA

API: American Petroleum Institute JASO: Japanese Automobile Standards Organization

NOTE: SUZUKI highly recommends the use of ECSTAR brand engine oil. ECSTAR has been specially formulated for your SUZUKI product and contributes to the desired motorcycle performance and ideal riding experience.

SAE Engine Oil Viscosity

Suzuki recommends the use of SAE 10W-40 engine oil. If SAE 10W-40 engine oil is not available, select an alternative according to the following chart.




* USE ONLY SG, SH, SJ or SL.

JASO T903

The JASO T903 standard is an index to select engine oils for 4motorcycle **ATV** stroke and engines. Motorcycle **ATV** and lubricate clutch enaines and transmission gears with engine oil. JASO T903 specifies performance requirements for motorcycle and ATV/ clutches and transmissions.

There are two classes, MA and MB. The oil container shows the classification as follows.



- 1 Code number of oil sales company
- 2 Oil classification

Energy Conserving

Suzuki does not recommend the use of "ENERGY CONSERVING" or "RESOURCE CONSERVING" oils. Some engine oils which have an API classification of SH, SJ, SL, SM or SN have an "ENERGY CONSERVING" or "RESOURCE CONSERVING" indication in the API classification donut mark. These oils can affect engine life and clutch performance.

API SG, SH, SJ, SL, SM or SN



Recommended







Not recommended

ENGINE COOLANT SOLUTION

Use "SUZUKI SUPER LONG or "SUZUKI LIFE COOLANT" LIFE COOLANT". LONG "SUZUKI SUPER LONG LIFE COOLANT" and "SUZUKI LONG LIFE COOLANT" are not available, use a glycol-based anticompatible freeze with an aluminum radiator mixed with distilled water only at the ratio of 50:50.

WARNING

Engine coolant is harmful or fatal if swallowed or inhaled. Solution can be poisonous to animals.

Do not drink antifreeze or coolant solution. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. Avoid inhaling mist or hot vapors; if inhaled, remove to fresh air. If coolant gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Keep out of the reach of children and animals.

NOTICE

Spilled engine coolant can damage the painted surfaces of your motorcycle.

Be careful not to spill any fluid when filling the radiator. Wipe spilled engine coolant up immediately.

NOTE: SUZUKI highly recommends the use of ECSTAR brand coolant. ECSTAR has been specially formulated for your SUZUKI product and contributes to the desired motorcycle performance and ideal riding experience.

ENGINE COOLANT

Engine coolant performs as a rust inhibitor and water pump lubricant as well as an anti-freeze solution. Therefore engine coolant should be used at all times even though the atmospheric temperature in your area does not go down to freezing point.

SUZUKI SUPER LONG LIFE COOLANT (Blue)

"SUZUKI SUPER LONG LIFE COOLANT" is pre-mixed to the proper ratio. Add only "SUZUKI SUPER LONG LIFE COOLANT" if coolant level drops. It is not necessary to dilute "SUZUKI SUPER LONG LIFE COOLANT" when replacing coolant.

SUZUKI LONG LIFE COOLANT (Green)

Water for Mixing

Use distilled water only. Water other than distilled water can corrode and clog the aluminum radiator.

Required amount of engine coolant/water solution capacity (total): 3000 ml (3.2 US qt)

Engine coolant	1500 ml (1.6 US qt)
Water	1500 ml (1.6 US qt)


NOTE: This 50% mixture will protect the cooling system from freezing at temperatures above -31°C (-24°F). If the motorcycle is to be exposed to temperature below -31°C (-24°F), this mixing ratio should be increased up to 55% (-40°C/-40°F) or 60% (-55°C/-67°F) coolant. The mixing ratio should not exceed 60% coolant.

CONTROLS, EQUIPMENT AND ADJUSTMENTS


LOCATION OF PARTS	3-2
KEY	3-5
IGNITION SWITCH	3-5
INSTRUMENT PANEL	3-8
LEFT HANDLEBAR	3-18
RIGHT HANDLEBAR	3-20
FUEL TANK CAP	3-24
GEARSHIFT LEVER	3-25
REAR BRAKE PEDAL	3-26
SEAT LOCK AND HELMET HOLDERS	3-26
SIDE STAND	3-28
SUSPENSION ADJUSTMENT	3-29
SEAT TAIL COVER	3-33

CONTROLS, EQUIPMENT AND ADJUSTMENTS


LOCATION OF PARTS



- 1 Clutch lever
- 2 Left handlebar switches
- 3 Clutch fluid reservoir
- 4 Instrument panel
- 5 Front brake fluid reservoir
- 6 Right handlebar switches
- 7 Throttle grip
- 8 Front brake lever
- 9 Ignition switch
- 10 Fuel tank cap




- 11 Seat lock
- 12 Helmet holders
- **13** Tools
- (4) Gearshift lever
- 15 Side stand



16 Rear brake pedal

KEY



Two keys come with this motorcycle. Keep the spare key in a safe place.

WARNING

Due to the location of the steering damper, some key chains could get caught between the steering damper and the steering stem nut. This could interfere with steering and cause loss of control.

Use your ignition key without key chains, fobs or other keys attached.

IGNITION SWITCH



The ignition switch has 4 positions:

"OFF" position

All electrical circuits are cut off. The engine will not start. The key can be removed.

"ON" position

The ignition circuit is completed and the engine can run. The headlight and taillight will automatically turn on. The key cannot be removed in this position.

NOTE: Start the engine promptly after turning the key to the "ON" position, or the battery will lose power due to consumption by the headlight and taillight.



"LOCK" position

All electrical circuits are off. The key can be removed and the steering will be locked. Turn the steering all the way to the left and push down the key and turn it to the "LOCK" position.

"P" (PARKING) position

Taillight will come on to increase visibility for temporary roadside parking at night. The key can be removed and the steering will be locked.

WARNING

Turning the ignition switch to the "P" (PARKING) or "LOCK" position while the motorcycle is moving can be hazardous. Moving the motorcycle while the steering is locked can be hazardous. You could lose your balance and fall, or you could drop the motorcycle.

Stop the motorcycle and place it on the side stand before locking the steering. Never attempt to move the motorcycle when the steering is locked.


WARNING

If the motorcycle falls down due to a slip or collision, unexpected damage to the motorcycle could cause the engine to keep running, which could result in a fire, or could result in injury from moving parts such as the rear wheel.

If the motorcycle falls down, turn the ignition switch off immediately. Ask your authorized Suzuki dealer to inspect the motorcycle for unseen damage.




The key hole can be covered by turning the lid.



Align the lid hole position with the key hole position when inserting the key.

INSTRUMENT PANEL



The fuel indicator light ⑤, oil pressure indicator light ⑦, engine coolant temperature indicator light ⑫, engine rpm indicator light ⑬, fuel injection system indicator light ⑮, LCD and meter needle work as follows to confirm their function when the ignition switch is turned to the "ON" position.

- The fuel indicator light ⑤, oil pressure indicator light ⑦, engine coolant temperature indicator light ⑫, engine rpm indicator light ⑬, fuel injection system indicator light ⑮ come on for 3 seconds.
- The meter needle moves to the full scale position and returns to the home position.
- All LCD segments appear/disappear and then show the normal display.

If the meter needle does not point to zero, follow the procedure below to reset the meter.

- Press and hold the ADJ button

 and turn on the ignition switch.
- 2. Hold the ADJ button (9) for 3 5 seconds.
- 3. Release the ADJ button (9). Rap the ADJ button twice.

NOTE: The reset procedure, from step 1 to step 3, should be performed within 10 seconds.

Fuel Meter "■" 1

The fuel meter indicates amount of gasoline remaining in the fuel tank. The "E" mark indicates the fuel tank is empty or nearly so. The "F" mark indicates the fuel tank is full.

NOTE: The fuel meter will not indicate correctly when the motorcycle is placed on the side stand. Turn the ignition switch to the "ON" position when the motorcycle is held upright.

Turn Signal Indicator Light "⇐⇒" ②

When the turn signals are being operated either to the right or to the left, the indicator light will blink intermittently.

NOTE: If a turn signal light is not operating properly due to bulb filament or circuit failure, the indicator light blinks more quickly to notify the rider of the existence of a problem.

Tachometer ③

The tachometer indicates the engine speed in revolutions per minute (r/min).

Gear Position Indicator (4)

The gear position indicator indicates gear position. This indicator displays "0" when the transmission is in neutral.


Fuel Indicator Light "■" ⑤

This indicator light comes on for 3 seconds when the ignition switch is turned to the "ON" position. Then the indicator light should go out if there is enough fuel in the tank. When the fuel in the fuel tank drops below approximately 5.0 L (1.3 US gal), this indicator light comes on and remains on.

NOTE: When the fuel indicator light comes on, you should add fuel to the fuel tank at the first opportunity to avoid running out of fuel.

Neutral Indicator Light "N" 6

The green light will come on when the transmission is in neutral. The light will go out when you shift into any gear other than neutral.



Oil Pressure Indicator Light " (7)

The oil pressure indicator light comes on when the engine oil pressure is below the normal operating range. The indicator light comes on when the ignition switch is turned on and the engine is not running. As soon as the engine starts, the indicator light should go off.

NOTICE

After starting the engine, opening the throttle or running the motorcycle with the oil pressure indicator light turned on may adversely affect the engine.

Make sure that the oil pressure indicator light has turned off before operating the throttle or running the motorcycle.

NOTICE

Riding the motorcycle with the oil pressure indicator light lit can damage the engine and transmission.

If the oil pressure indicator light comes on, indicating low oil pressure, stop the engine immediately. Check the oil level and add oil if necessary. If there is a proper amount of oil and the light still does not go out, have your authorized Suzuki dealer or a qualified mechanic inspect your motorcycle.

Clock ®

The clock has a 12-hour display. Follow the procedure below to adjust the clock.

- Push the SEL button ⑦ and the ADJ button ⑨, simultaneously for 2 seconds until the hour display blinks.
- 2. Adjust the hour display by pushing the ADJ button (9).

NOTE: When the ADJ button (9) is held in, the display advances continuously.

- 3. Push the SEL button ① to highlight the minute display.
- 4. Adjust the minute display by pushing the ADJ button ⁽⁹⁾.
- 5. Push the SEL button ① to return to the clock mode.

Suzuki Drive Mode Indicator (9)
The Suzuki drive mode indicator displays drive mode; A, B and C when the Suzuki drive mode selector is activated. Refer to the RIGHT HANDLEBAR section for

Speedometer 10

detail.

The speedometer indicates the road speed in miles per hour and/ or kilometers per hour.

Engine Coolant Temperature Meter "£" 11

The engine coolant temperature meter indicates coolant temperature. When the coolant temperature gets too much high, the engine coolant temperature indicator light ② comes on, stop the engine and check the coolant level after the engine cools.

NOTICE


Riding the motorcycle with the engine coolant temperature indicator light lit can cause serious engine damage due to overheating.

If the engine coolant temperature indicator light comes on, stop the engine to let it cool. Do not run the engine until the engine coolant temperature indicator light goes off. NOTE: The needle points "H" when the engine stop switch is turned to the "OFF" position with the ignition switch in "ON" position.

Engine RPM Indicator ③, "②" ⑥ The engine rpm indicator light ③ will light or blink when the engine speed reaches a preset engine rpm.

Lighting mode, light brightness and preset engine rpm can be set using the selection mode. To enter the selection mode, press and hold the SEL button $^{\textcircled{m}}$ and turn on the ignition switch. Hold the button for more than 2 seconds to change the mode.

NOTE: The instrument panel memorizes the engine rpm indicator setting data when the ignition switch is turned off. However, the memory data will be cleaned when the battery power supply is cut off.



Light/Blink/No Light Selection

Push the ADJ button 19 to change lighting mode. The mode the changes as follows: LIGHT → BLINK → NO LIGHT → LIGHT. The engine rpm indicator light (3) comes on steady in the LIGHT mode and blinks in the BLINK mode. The engine rpm indicator mark "(2)" (6) comes on when the mode is in LIGHT or BLINK mode is selected. When the SEL button 17 is pushed in the NO LIGHT mode, the selection mode is canceled. The selection mode is also canceled when the motorcycle speed exceeds 10 km/h (7 mph).

Light Brightness Selection

Push the SEL button ① and the brightness indicator comes on in odometer/trip meter area. Pushing the ADJ button ③ will change light brightness in 5 steps. The brightness indicator indicates brightness from "a" (min) to "aaaaa" (max).

Preset rpm Selection

Push the SEL button ⑦ from the light brightness selection mode. Push the ADJ button ⑨ to select preset a rpm. Push the ADJ button ⑨ to change the preset rpm from 4000 r/min to 8000 r/min in steps of 500 r/min and from 8000 r/min to 11500 r/min in steps of 250 r/min.

Push the SEL button ① to fix the selected setting. The engine rpm indicator system holds the selected settings when the ignition switch is turned off. The system settings will remain when the ignition switch is turned on again.

ABS INDICATOR LIGHT "(@9)" (4)

This indicator normally comes on when the ignition switch is turned "ON" and goes off after the motorcycle speed exceeds 6 mph (10 km/h).

If there is a problem with the ABS (Anti-lock Brake System), this indicator light blinks or comes on. The ABS does not operate when the ABS indicator light is on or blinking.


NOTE: If the ABS indicator light goes off after you start the motorcycle but before you begin riding, check the ABS indicator light function by turning off and on the ignition switch. The ABS indicator light can go off if the engine is revved at high speed before you begin riding. If the ABS indicator light does not come on when the ignition switch is turned on, you should have the system checked by an authorized Suzuki dealer as soon as possible.

WARNING

Riding the motorcycle with the ABS indicator light on can be hazardous.

If the ABS indicator light blinks or comes on while riding, stop the motorcycle in a safe place and turn off the ignition switch. Turn the ignition switch "ON" after a while and check if the indicator light comes on.


- If the indicator light goes off after starting to ride, the ABS will be functioning.
- If it does not go off after starting to ride, ABS is not functioning, and the brakes provide normal stopping ability. You should have the system checked by an authorized Suzuki dealer as soon as possible.



Odometer/Trip Meter/ Fuel Injection System Indicator "FI" ®

The indicator displays odometer/ trip meter under normal condition. When the ignition switch is turned to the "ON" position, the test pattern shown below is displayed. The display is memorized when the ignition switch is turned off and the memorized display appears when the ignition switch is turned on again.

To change the display, push the SEL button $\widehat{\mathbb{T}}$. The display changes in the order below.



Odometer

The odometer registers the total distance that the motorcycle has been ridden. The odometer ranges from 0 to 999999.

NOTE: The odometer display locks at 999999 when the total distance exceeds 999999.

Trip meters

The 2 trip meters are resettable odometers. They can register 2 kinds of distances at the same time. For instance, trip meter 1 can register the trip distance and trip meter 2 can register the distance between fuel stops.

To reset the meter to zero, push the ADJ button (9) for 2 seconds while the display indicates the trip meter 1, or 2, you want to reset.


NOTE: When the trip meter exceeds 9999.9, the trip meter will return to 0.0 and start counting again.

NOTE: The trip meter will be reset to zero when the battery is removed or battery is discharged.

WARNING

Changing the display while riding can be hazardous. Removing a hand from the handlebars can reduce your ability to control the motorcycle.

Never change the display while riding. Keep both hands on the handlebars.



Fuel injection system indicator



If the fuel injection system fails, the red indicator light (5) comes on and the display (8) indicates "FI" in the odometer/trip meter display area in the following 2 modes;

- A. The display [®] in the odometer/trip meter display area alternately indicates "FI" and the odometer/trip meter reading, and the red indicator light [®] comes on and remains lit.
- B. The display ® in the odometer/trip meter display area indicates "FI" continuously and the red indicator light ® blinks.

The engine may continue to run in mode A, but the engine will not run in mode B.

NOTICE

The fuel injection indicator light comes on to indicate a problem with the fuel injection system.

If the display indicates "FI" and the red indicator light comes on, have your authorized Suzuki dealer or a qualified mechanic inspect the fuel injection system as soon as possible.

NOTE: If the display indicates "FI" continuously and the red indicator light blinks, the engine will not start.



When the display indicates "CHEC" in the odometer/trip meter display area, check the following items;

- Make sure that the engine stop switch is in the "○" position.
- Make sure that the transmission is in neutral or the side stand is fully up.


If the display still indicates "CHEC" after checking the above items, inspect the ignition fuse and the connection of the lead wire couplers.

High Beam Indicator Light "≣⊘"

20

This blue indicator light will be lit when the headlight high beam is turned on.


LEFT HANDLEBAR



Clutch Lever (1)

The clutch lever is used for disengaging the drive to the rear wheel when starting the engine or shifting transmission gears. Squeezing the lever disengages the clutch.

Clutch Lever Adjustment



The distance between the grip and the clutch lever is adjustable to 4 positions. To change the position, push the clutch lever forward and turn the adjuster to the desired position. When changing the clutch lever position, always be sure the adjuster stops in the proper position; a projection of the clutch lever pivot should fit into the depression of the adjuster. This motorcycle is delivered from the factory with its adjuster set on position 2.

WARNING

Adjusting the clutch lever position while riding can be hazardous. Removing a hand from the handlebars can reduce your ability to control the motorcycle.

Never adjust the clutch lever position while riding. Keep both hands on the handlebars.

Headlight Flasher Switch 2

Press the switch to flash the headlight high beam. The headlight high beam will flash when the dimmer switch is in the "

"position."

Dimmer Switch ③

"≨○" position

The headlight low beam turns on.

"≣⊳" position

The headlight high beam turns on. The high beam indicator light also comes on.

NOTICE

Sticking tape or placing objects in front of the headlight can obstruct headlight heat radiation. This can result in headlight damage.

Do not stick tape on the headlight or place objects in front of the headlight.

NOTICE

Do not put objects in front of the headlight or taillight when they are on, and do not cover with clothes when the motorcycle is stopped.

This may cause melting of the lens or damage to the object by the heat from the lens.

Hazard Warning Switch "A" (4) All four turn signal lights and indicators will flash simultaneously when the switch is turned on with the ignition switch in the "ON" or "P" position. Use the hazard warning lights to warn other traffic during emergency parking or when your vehicle could otherwise become a traffic hazard.

Turn Signal Light Switch

"⇐⇒" 5

Moving the switch to the " \leftrightarrows " position will flash the left turn signals. Moving the switch to the " \Longrightarrow " position will flash the right turn signals. The indicator light will also flash intermittently. To cancel turn signal operation, push the switch in.

WARNING


Failure to use the turn signals, and failure to turn off the turn signals can be hazardous. Other drivers may misjudge your course and this may result in an accident.

Always use the turn signals when you intend to change lanes or make a turn. Be sure to turn off the turn signals after completing the turn or lane change.

Horn Switch "├─" ⑥

Press the switch to sound the horn.

RIGHT HANDLEBAR



Engine Stop Switch ① "X" position

The ignition circuit is off. The engine cannot start or run.


"○" position

The ignition circuit is on and the engine can run.

Front Brake Lever 2

Apply the front brake by squeezing the front brake lever towards the grip. The brake light will come on when the lever is squeezed.

Front Brake Lever Adjustment



The distance between the throttle grip and the front brake lever is adjustable to 5 positions. To change the position, push the brake lever forward and turn the adjuster to the desired position. When changing the brake lever position, always be sure the adjuster stops in the proper position; a projection of the brake lever pivot should fit into the depression of the adjuster. This motorcycle is delivered from the factory with its adjuster set on position 3.

WARNING

Adjusting the front brake lever position while riding can be hazardous. Removing a hand from the handlebars can reduce your ability to control the motorcycle.

Never adjust the front brake lever position while riding. Keep both hands on the handlebars.

Electric Starter Switch " (\mathfrak{T}) " (\mathfrak{T}) " Use this switch to operate the starter motor. With the ignition switch in the "ON" position, the engine stop switch in the " (\mathfrak{T}) " position, and the transmission in neutral, squeeze the clutch lever and push the electric starter switch to start the engine.

NOTE: This motorcycle has a starter interlock system for the ignition and starter circuit. The engine can only be started if:

- The transmission is in neutral and the clutch is disengaged, or
- The transmission is in gear, the side stand is fully up and the clutch is disengaged.

NOTE: The headlight will go off when the electric starter switch is pushed.

NOTICE

Engaging the starter motor for more than five seconds at a time can damage the starter motor and wiring harness from overheating.


Do not engage the starter motor for more than five seconds at a time. If the engine does not start after several attempts, check the fuel supply and ignition system. Refer to the TROUBLESHOOTING section in this manual.

NOTICE


If the neutral indicator light and the gear position indicator are not giving proper indications, starting the engine can cause serious engine damage.

Before starting the engine, make sure of the followings:

- When the neutral indicator light comes on, the gear position indicator should indicate "0" (Neutral).
- When the neutral indicator light goes off, the gear position indicator should indicate either "1", "2", "3", "4", "5" or "6".
- If the neutral indicator light and the gear position indicator are not working properly, consult your Suzuki dealer.



Suzuki Drive Mode Selector 4 Engine power characteristics can be selected from 3 modes by operating the drive mode selector to suit rider's preference in various riding conditions.



Suzuki drive mode selector operation

Drive mode is preset at A-mode when the ignition switch and the engine stop switch are turned on. At this time, the Suzuki drive mode indicator shows nothing. Follow the procedure below to operate the Suzuki drive mode selector.


- 1. Turn on the ignition switch and the engine stop switch.
- 2. Start the engine.
- Push the Suzuki drive mode selector for 2 seconds until the Suzuki drive mode indicator shows A.
- 4. Push the Suzuki drive mode selector to change drive mode. Pushing the upper part can change from A to C to B to A. Pushing the lower part can change from A to B to C to A. The Suzuki drive mode indicator indicates actual drive mode.

NOTE:

- Operating the Suzuki drive mode selector while riding with the throttle opened will change the engine speed because of engine power characteristics change.
- The Suzuki drive mode indicator blinks when drive mode change operation is failed.
- Turning off the ignition switch or the engine stop switch will return the drive mode to Amode. Start the engine and reset the drive mode.

Drive mode

Engine power



Throttle opening

A-mode

A-mode provides sharp throttle response at all throttle opening range to obtain maximum engine power.

B-mode

B-mode provides softer throttle response than A-mode at all throttle opening range.


C-mode


C-mode provides softer throttle response than B-mode at all throttle opening range.

Throttle Grip 5

Engine speed is controlled by the position of the throttle grip. Twist it toward you to increase engine speed. Turn it away from you to decrease engine speed.


FUEL TANK CAP





To open the fuel tank cap, insert the ignition key into the lock and turn it clockwise. With the key inserted, lift up with the key and open the fuel tank cap. To close the fuel tank cap, push the cap down firmly with the key in the cap lock.

Use fresh gasoline when filling up the fuel tank. Do not use bad gasoline which is contaminated with dirt, dust, water or other liquid. Be careful that dirt, dust or water do not enter the fuel tank when refueling.



- 1) Fuel level
- ② Filler neck

WARNING

If you overfill the fuel tank, fuel may overflow when it expands due to engine heat or heating by the sun. Fuel that overflows can catch fire.


Stop adding fuel when the fuel level reaches the bottom of the filler neck.

WARNING

Failure to follow safety precautions when refueling could result in a fire or cause you to breathe toxic fumes.

Refuel in a well ventilated area. Make sure the engine is off and avoid spilling fuel on a hot engine. Do not smoke, and make sure there are no open flames or sparks in the area. Avoid breathing gasoline vapors. Keep children and pets away when you refuel the motorcycle.


GEARSHIFT LEVER



This motorcycle has a 6-speed transmission which operates as shown. To shift properly, squeeze the clutch lever and close the throttle at the same time you operate the gearshift lever. Lift the gearshift lever to upshift and depress the lever to downshift. Neutral is located between 1st and 2nd gear. When neutral is desired, depress or lift the lever halfway between 1st and 2nd gear.

NOTE: When the transmission is in neutral, the green indicator light on the instrument panel will be lit. However, even though the light is illuminated, cautiously and slowly release the clutch lever to make sure that the transmission is positively in neutral.

REAR BRAKE PEDAL




Depressing the rear brake pedal will apply the rear disk brake. The brake light will be illuminated when the rear brake is operated.


SEAT LOCK AND HELMET HOLDERS

Front Seat

To remove the front seat.



- 1. Remove the right and left bolts ①.
- 2. Raise the front end of the seat and slide it forward.




To reinstall the seat, slide the seat hooks into the seat hook retainers on the frame and tighten the bolts securely.

WARNING


Failure to install the seat properly could allow the seat to move and cause loss of rider control.

Fasten the seat securely in its proper position.

Rear Seat



The seat lock is located under the left frame cover. To remove the rear seat, insert the ignition key into the lock and turn it clockwise.



Raise the rear end of the seat and slide it backward.




To reinstall the seat, slide the seat hooks into the seat hook retainers and push down firmly until the seat snaps into the locked position.

WARNING

Failure to install the seat properly could allow the seat to move and cause loss of rider control.

Latch the seat securely in its proper position.

Helmet Holders




This motorcycle has helmet holders under the rear seat. Hook your helmet on the helmet holder and lock the seat.

WARNING

Riding with a helmet fastened to the helmet holder can interfere with rider control.

Never carry a helmet fastened to the helmet holder. Fix the helmet securely atop the seat if you must carry it.

SIDE STAND



An interlock system is provided to cut off the ignition circuit when the side stand is down and the transmission is in any gear other than neutral.

The side stand/ignition interlock system works as follows:

- If the side stand is down and the transmission is in gear, the engine can not be started.
- If the engine is running and the transmission is shifted into gear with the side stand down, the engine will stop running.
- If the engine is running and the side stand is put down with the transmission in gear, the engine will stop running.

WARNING

Riding with the side stand incompletely retracted can result in an accident when you turn left.

Check operation of the side stand/ignition interlock system before riding. Always retract the side stand completely before starting off.

NOTICE

If you do not take proper precautions when parking, the motorcycle can fall over.

Park the motorcycle on firm, level ground whenever possible. If you must park on an incline, aim the front of the motorcycle uphill and put the transmission into 1st gear to reduce the possibility of rolling off the side stand.

SUSPENSION ADJUSTMENT


The standard settings of both front and rear suspensions are selected to meet various riding conditions such as low to high motorcycle speed and light to heavy load on the motorcycle. The suspension settings can be adjusted and fine-tuned according to your preference.

NOTICE

Turning adjusters by force can damage the suspensions.

Do not turn adjusters beyond their natural limits.

FRONT SUSPENSION Spring Pre-load Adjustment




To set the spring pre-load to the standard position, turn the adjuster ① clockwise until it stops and then turn it counterclockwise 6 turns

Turn the adjuster clockwise from the standard position to stiffen the spring pre-load. Turn the adjuster counterclockwise to soften the spring pre-load.

Damping Force Adjustment


The rebound and compression damping force can be individually adjusted by turning the respective adjusters. The rebound damping force adjuster ② is located at the top of the front suspension. The compression damping force adjusters ③ are located at the bottom of the front suspension.

To adjust the damping force, set the adjuster to the standard setting first and then adjust the adjuster to the desired position.



To set the rebound damping force adjuster to the standard position, turn the adjuster clockwise until it stops and then turn it counterclockwise 8 clicks.

Turn the adjuster clockwise from the standard position to stiffen the damping force. Turn the adjuster counterclockwise to soften the damping force. The damping force should be adjusted gradually, 1 click at a time, to fine-tune the suspension.



To set the compression damping force adjuster to the standard position, turn the adjuster clockwise until it stops and then turn it counterclockwise 8 clicks.

Turn the adjuster clockwise from the standard position to stiffen the damping force. Turn the adjuster counterclockwise to soften the damping force. The damping force should be adjusted gradually, 1 click at a time, to fine-tune the suspension.


NOTE: Do not loosen the adjuster base ⓐ, or front fork oil will ooze through the adjuster base.

WARNING

Unequal suspension adjustment can cause poor handling and instability.

Adjust the right and left front forks to the same setting.

REAR SUSPENSION Spring Pre-load Adjustment



The adjustment can be performed by changing the adjuster ring position. However, Suzuki recommends that this adjustment be done by your authorized Suzuki dealer, since a special tool is needed for this job.

Rear Suspension Label

A WARNING



sion.





This unit contains high-pressure nitrogen gas.

Mishandling can cause explo-


- Keep away from fire and heat.
- Read owner's manual for more information.

NOTE: Ask your Suzuki dealer to dispose of the rear suspension unit.

Damping Force Adjustment


The rebound and compression damping force can be individually adjusted by turning the respective adjusters. The rebound damping force adjuster ① is located at the bottom of the rear suspension. The compression damping force adjusters ② are located at the left side of the rear suspension.

To adjust the damping force, set the adjuster to the standard setting first and then adjust the adjuster to the desired position.



To set the rebound damping force adjuster to the standard position, turn the adjuster clockwise until it stops and then turn it counterclockwise 12 clicks until the two punch marks align. If the two punch marks do not align by turning out 12 clicks, turn in or out the adjuster until two punch marks align.

Turn the adjuster clockwise from the standard position to stiffen the damping force. Turn the adjuster counterclockwise to soften the damping force. The damping force should be adjusted gradually, 1 click at a time, to fine-tune the suspension.




To set the compression damping force adjuster to the standard position, turn the adjuster clockwise until it stops and then turn it counterclockwise 8 clicks until the two punch marks align. If the two punch marks do not align by turning out 8 clicks, turn in or out the adjuster until two punch marks align.

Turn the adjuster clockwise from the standard position to stiffen the damping force. Turn the adjuster counterclockwise to soften the damping force. The damping force should be adjusted gradually, 1 click at a time, to fine-tune the suspension.


SEAT TAIL COVER

A seat tail cover for solo riding can be attached to the motorcycle. To replace the rear seat with the seat tail cover, follow the procedure below.




- 1. Remove the rear seat.
- 2. Remove the passenger hand rail by removing the 4 bolts.

NOTE: The washer and the cushion detachable with the passenger hand rail will become necessary when the passenger hand rail should be installed again. Keep and store them together with the passenger hand rail.



Install the attached washer and tighten the removed 4 bolts to the specified torque.

Passenger hand rail bolt tightening torque: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)



4. Install the seat tail cover.

To remove the seat tail cover.

- Remove the seat tail cover by taking the reverse procedures of installing.
- 2. Tighten the 4 bolts fixing the passenger hand rail to the specified torque.

Passenger hand rail bolt tightening torque: 33 N·m (3.3 kgf-m, 24.0 lbf-ft)

WARNING

If the bolts are not properly tightened, the passenger hand rail can come off, causing an accident.

Be sure to tighten the bolts to the specified torque. If you do not have a torque wrench or do not know how to use one, ask your authorized Suzuki dealer to check the bolts.



4

BREAK-IN AND INSPECTION BEFORE RIDING

BREAK-IN	4-2
INSPECTION REFORE DIDING	1-3

BREAK-IN AND INSPECTION BEFORE RIDING

BREAK-IN

The first 800 km (500 miles) is the most important in the life of your motorcycle. Proper operation during this break-in period will help assure maximum life and performance from your new motorcycle. The following guidelines explain proper break-in procedures.

Maximum Engine Speed Recommendation

The table below shows the maximum engine speed recommendation during the break-in period.

Initial 800 km	Below
(500 miles)	5500 r/min
Up to 1600 km	Below
(1000 miles)	8000 r/min
Over 1600 km	Below
(1000 miles)	11000 r/min

Vary the Engine Speed

Vary the engine speed during the break-in period. This allows the parts to "load" (aiding the mating process) and then "unload" (allowing the parts to cool). Although it is essential to place some stress on the engine components during break-in, you must be careful not to load the engine too much.

Breaking in the New Tires

New tires need proper break-in to assure maximum performance, just as the engine does. Wear- in the tread surface by gradually increasing your cornering lean angles over the first 160 km (100 miles) before attempting maximum performance. Avoid hard acceleration, hard cornering, and hard braking for the first 160 km (100 miles).

WARNING

Failure to perform break-in of the tires could cause tire slip and loss of control.

Use extra care when riding on new tires. Perform proper break-in of the tires as described in this section and avoid hard acceleration, hard cornering, and hard braking for the first 160 km (100 miles).

Observe Your Initial and Most Critical Service

The initial service (break-in maintenance) is the most important motorcycle service your receive. During break-in operation, all of the engine components will have mated together and seated. Maintenance required as part of the initial service includes correction of all adjustments, tightening of all fasteners and replacement of dirty oil. Timely performance of this service will help make sure you get the best service life and performance from the engine.

NOTE: The 1000 km (600 miles) service should be performed as outlined in the INSPECTION AND MAINTENANCE section of this Owner's Manual. Pay particular attention to the CAUTION and WARNING messages in that section.

INSPECTION BEFORE RIDING

WARNING

Failure to inspect your motorcycle before riding and to properly maintain your motorcycle increases the chances of an accident or equipment damage.

Always inspect your motorcycle each time you use it to make sure it is in safe operating condition. Refer to the INSPECTION AND MAINTE-NANCE section in this owner's manual.

WARNING

If you operate this motorcycle with improper tires or improper or uneven tire pressure, you may lose control of the motorcycle. This will increase your risk of an accident.

Always use tires of the size and type specified in this owner's manual. Always maintain proper tire pressure as described in the INSPECTION AND MAINTENANCE section.

Check the condition of the motor-cycle to help make sure that you do not have mechanical problems or get stranded somewhere when you ride. Before riding the motor-cycle, be sure to check the following items. Be sure your motorcycle is in good condition for the personal safety of the rider, passenger and protection of the motorcycle.

WARNING

Checking maintenance items when the engine is running can be hazardous. You could be severely injured if your hands or clothing get caught in moving engine parts.

Shut the engine off when performing maintenance checks, except when checking the lights, engine stop switch, and throttle.

WHAT TO CHECK	CHECK FOR:
Steering	SmoothnessNo restriction of movementNo play or looseness
Throttle (CF 7-24)	Correct play in the throttle cable Smooth operation and positive return of the throttle grip to the closed position
Clutch (CF 7-26)	Fluid level in the reservoir to be above "LOWER" line Correct lever play No fluid leakage Smooth and progressive action

Brakes (3-20, 3-26, 7-33)	Proper pedal and lever operation Iluid level in the reservoir to be above "LOWER" line Correct pedal and lever play No "sponginess" No fluid leakage Brake pads not worn down to the limit line
Suspension (3-29)	Smooth movement
Fuel (3-8, 3-9)	Enough fuel for the planned distance of operation
Drive chain (F7 7-29)	Correct tension or slack Adequate lubrication No excessive wear or damage
Tires (7-37)	Correct pressure Adequate tread depth No cracks or cuts
Engine oil (7-18)	Correct level
Cooling system (7-27)	Proper coolant level No coolant leakage
Lighting (3-5, 3-8, 3-18)	Operation of all lights and indicators
Horn (3-19)	Correct function
Engine stop switch (3-20)	Correct function
Side stand/ Ignition interlock system (- 7-41)	Proper operation
Windshield (☐₹ 9-7)	Good visibility

RIDING TIPS

STARTING THE ENGINE	5-2
STARTING OFF	5-4
USING THE TRANSMISSION	5-5
RIDING ON HILLS	5-6
STOPPING AND PARKING	5-7
CARRYING A PASSENGER	5-10

RIDING TIPS

STARTING THE ENGINE

Before attempting to start the engine, make sure:

- 1. The transmission is in neutral.
- 2. The engine stop switch is in the "○" position.

NOTE: This motorcycle has a starter interlock system for the ignition and starter circuit. The engine can only be started if:

- The transmission is in neutral and the clutch is disengaged, or
- The transmission is in gear, the side stand is fully up and the clutch is disengaged.

NOTE: The fuel supply system stops the engine when the motorcycle is overturned. Turn off the ignition switch before restarting the engine.

NOTICE

If the neutral indicator light and the gear position indicator are not giving proper indications, starting the engine can cause serious engine damage.

Before starting the engine, make sure of the followings:

- When the neutral indicator light comes on, the gear position indicator should indicate "0" (Neutral).
- When the neutral indicator light goes off, the gear position indicator should indicate either "1", "2", "3", "4", "5" or "6".
- If the neutral indicator light and the gear position indicator are not working properly, consult your Suzuki dealer.

When the Engine is Cold:

Close the throttle completely and push the electric starter switch.

When a Cold Engine is Hard to Start:

Open the throttle approximately 1/8 turn and push the electric starter switch.

When the Engine is Warm:

Close the throttle completely and push the electric starter switch.

When a Warm Engine is Hard to Start:

Open the throttle approximately 1/8 turn and push the electric starter switch.

WARNING

Exhaust gas contains carbon monoxide, a dangerous gas that is difficult to detect because it is colorless and odorless. Breathing carbon monoxide can cause death or severe injury.

Never start the engine or let it run indoors or where there is little or no ventilation.

NOTICE

After starting the engine, opening the throttle or running the motorcycle with the oil pressure indicator light turned on may adversely affect the engine.

Make sure that the oil pressure indicator light has turned off before operating the throttle or running the motorcycle.

NOTICE

Running the engine too long without riding may cause the engine to overheat. Overheating can result in damage to internal engine components and discoloration of exhaust pipes.

Shut the engine off if you cannot begin your ride promptly.

WARNING

Riding at excessive speeds increases your chances of losing control of the motorcycle, which can result in an accident.

Always ride at a speed that is proper for the terrain, visibility and operating conditions, and your skills and experience.

A WARNING

If you remove even one hand or foot from the motorcycle, you can reduce your ability to control the motorcycle. This could cause you to lose your balance and fall off the motorcycle. If you remove a foot from a footrest, your foot or leg may come in contact with the rear wheel. This could injure you or cause an accident.

Always keep both hands on the handlebars and both feet on the footrests of your motorcycle during operation.

WARNING

Sudden side winds, which can occur when being passed by larger vehicles, at tunnel exits or in hilly areas, can cause you to lose control of the motorcycle.

Reduce your speed and be alert to the possibility of sudden side winds.

Make sure that the side stand is in the fully up position. Squeeze the clutch lever and pause momentarily. Engage first gear depressing the gearshift lever downward. Turn the throttle grip toward you and at the same time release the clutch lever gently and smoothly. As the clutch engages, the motorcycle will start moving forward. To shift to the next higher gear, accelerate gently, then close the throttle and squeeze the clutch lever simultaneously. Lift the gear shift lever upward to select the next gear and release the clutch lever as you open the throttle again. Select higher gears in this manner until top gear is reached.

NOTE: This motorcycle has a side stand/ignition interlock system. If you shift the transmission into gear when the side stand is down, the engine will stop running.

USING THE TRANSMISSION

The transmission is provided to keep the engine operating smoothly in its normal operating speed range. The gear ratios have been carefully chosen to meet the characteristics of the engine. The rider should always select the most suitable gear for the prevailing conditions. Never slip the clutch to control road speed, but rather downshift to allow the engine to run within its normal operational range. The table below shows the approximate speed range for each gear.

Shifting up schedule

Gear position	mph	km/h
1st \rightarrow 2nd	12	20
2nd \rightarrow 3rd	19	30
$3rd \rightarrow 4th$	25	40
4th \rightarrow 5th	31	50
5th \rightarrow 6th	37	60

Shifting down schedule

Gear position	mph	km/h
$6\text{th} \rightarrow 5\text{th}$	31	50
5th $ ightarrow$ 4th	25	40
4th \rightarrow 3rd	19	30

Disengage the clutch when the motorcycle speed drops below 14 mph (23 km/h).

A WARNING

Downshifting when engine speed is too high can:

- cause the rear wheel to skid and lose traction due to increased engine braking, resulting in an accident; or
- force the engine to overrev in the lower gear, resulting in engine damage.

Reduce speed before downshifting.

WARNING

Downshifting while the motorcycle is leaned over in a corner may cause rear wheel skid and loss of control.

Reduce your speed and downshift before entering a corner.

NOTICE

Revving the engine into the red zone can cause severe engine damage.

Never allow the engine to revinto the red zone in any gear.

NOTICE

Improper gearshift lever operation can damage the transmission.

- Do not rest your foot on the gearshift lever.
- Do not use force to shift gears.

RIDING ON HILLS

- When climbing steep hills, the motorcycle may begin to slow down and show lack of power. At this point you should shift to a lower gear so that the engine will again be operating in its normal power range. Shift rapidly to prevent the motorcycle from losing momentum.
- When descending a long, steep slope, use the engine compression to assist the brakes by shifting to a lower gear. Continuous brake application can overheat the brakes and reduce their effectiveness.
- Be careful, however, not to allow the engine to overrev.

STOPPING AND PARKING Anti-lock Brake System (ABS)

This model is equipped with an Anti-lock Brake System (ABS) designed to help prevent wheel lock up during hard braking or during braking on slippery surfaces while riding in a straight line.

The ABS will operate whenever it senses that the wheels are locking up. You may feel the brake lever and/or the brake pedal pulsate lightly while the ABS is operating.

Even though ABS helps prevent wheel lock-up, you must still be careful when braking in curves. Hard braking while turning could cause wheel skidding and loss of control, whether or not your motorcycle is equipped with ABS. Having ABS does not mean you can take unnecessary risks. ABS will not compensate for poor judgment, incorrect braking techniques, or not slowing down over bad roads or in poor weather conditions.

You must still ride sensibly and alertly.

On regular paved roads, some riders may be able to obtain slightly shorter stopping distances with conventional brake systems than with ABS.

NOTE: In some situations, a motorcycle with ABS may require a longer stopping distance to stop on loose or uneven surfaces than an equivalent motorcycle without ABS.

AWARNING

Inexperienced riders tend to underutilize the front brake. This can cause excessive stopping distance and lead to a collision. Using only the front or rear brake can cause skidding and loss of control.

Apply both brakes evenly and at the same time.

AWARNING

Braking while turning the motorcycle can be hazardous, whether or not your motorcycle is equipped with ABS. ABS can not control wheel side-slips that occur when you brake hard while turning and the side-slips could cause loss of control.

Slow down sufficiently in a straight line before you begin to turn and avoid other than slight braking while turning.

AWARNING

Failure to use good judgment with ABS can be hazardous. ABS cannot make up for bad road conditions, bad judgement, or improper operation of the brakes.

Remember that ABS will not compensate for poor judgment, incorrect braking techniques, or the need to slow down over bad roads or in poor weather conditions. Use good judgment and do not ride faster than conditions will safely allow.

How the ABS Works

ABS works by electronically controlling braking pressure. A computer monitors wheel rotation speed. If the computer detects that a braked wheel has slowed suddenly, indicating a skidding situation, the computer will reduce braking pressure to prevent that wheel from locking up. ABS works automatically, so you do not need any special braking technique. Just squeeze the front brake lever and rear brake lever, as forcefully as necessary for the situation, without pumping either one. It is normal for the brake levers to pulsate while the ABS is operating.

Non-recommended tires can affect wheel speed and may confuse the computer.

ABS does not work at very low speed, less than 6 mph (10 km/h), and does not work with a discharged battery.

Stopping and Parking

- 1. Twist the throttle grip away from yourself to close the throttle completely.
- 2. Apply the front and rear brakes evenly and at the same time.
- 3. Downshift through the gears as road speed decreases.
- Select neutral with the clutch lever squeezed toward the grip (disengaged position) when the motorcycle is almost completely stopped. The neutral position can be confirmed by observing the neutral indicator light.

WARNING

Inexperienced riders tend to underutilize the front brake. This can cause excessive stopping distance and lead to a collision. Using only the front or rear brake can cause skidding and loss of control.

Apply both brakes evenly and at the same time.

AWARNING

Hard braking while turning may cause wheel skid and loss of control.

Brake before you begin to turn.

WARNING

Hard braking on wet, loose, rough, or other slippery surfaces can cause wheel skid and loss of control.

Brake lightly and with care on slippery or irregular surfaces.

A WARNING

Following another vehicle too closely can lead to a collision. As vehicle speeds increase, stopping distance increases progressively.

Always maintain a safe stopping distance between you and the vehicle in front of you.

NOTICE

Holding the motorcycle stopped with throttle and clutch lever operation on inclines can damage the motorcycle's clutch.

Use the brakes when stopping the motorcycle on inclines.

Park the motorcycle on a firm, flat surface where it will not fall over.

A CAUTION

A hot muffler can cause severe burns. The muffler will be hot enough to cause burns for some time after stopping the engine.

Park the motorcycle where pedestrians or children are not likely to touch the muffler.

NOTE: If the motorcycle is to be parked on the side stand on a slight slope, the front end of the motorcycle should face "up" the incline to avoid rolling forward off the side stand. You may leave the motorcycle in 1st gear to help prevent it from rolling off the side stand. Shift to neutral before starting the engine.

- 6. Turn the ignition switch to the "OFF" position.
- Turn the handlebars all the way to the left and lock the steering for security.
- 8. Remove the ignition key.

NOTE: If an optional anti-theft lock such as a U-shape lock, brake disk lock or chain is used to avoid theft, be sure to remove the anti-theft lock before moving the motorcycle.

CARRYING A PASSENGER

Before you invite someone to be a passenger on your motorcycle, you need to be thoroughly familiar with motorcycle operation. Adjust tire pressures and suspension according to the Tire Pressure and Loading section and the Suspension section of this manual.

The passenger should always hold onto your waist or hips, or onto the seat strap or grab bar, as equipped. Ask your passenger not to make any sudden movements. When you lean going around a corner, the passenger should lean with you. The passenger should always keep his or her feet on the footrests, even when you are stopped at a light.

To help prevent burn injuries, warn your passenger not to contact the muffler when mounting or dismounting your motorcycle.

ACCESSORY USE AND MOTORCYCLE LOADING

ACCESSORY USE	6-2
ACCESSORY INSTALLATION GUIDELINES	6-2
LOADING LIMIT	6-3
LOADING GUIDELINES	6-4
MODIFICATION	6-5

ACCESSORY USE AND MOTORCYCLE LOADING

ACCESSORY USE

The addition of unsuitable accessories can lead to unsafe operating conditions. It is not possible for Suzuki to test each accessory on the market or combinations of all the available accessories; however, your dealer can assist you in selecting quality accessories and installing them correctly. Use extreme caution when selecting and installing the accessories on your motorcycle and consult your Suzuki dealer if you have any questions.

WARNING

Improper installation of accessories or modification of the motorcycle may cause changes in handling which could lead to an accident.

Never use improper accessories, and make sure that any accessories that are used are properly installed. All parts and accessories added to the motorcycle should be genuine Suzuki parts or their equivalent designed for use on this motorcycle. Install and use them according to their instructions. If you have any questions, contact your Suzuki dealer.

ACCESSORY INSTALLATION GUIDELINES

- Install aerodynamic-affecting accessories, such as a fairing, windshield, backrests, saddlebags, and travel trunks, as low as possible, as close to the motorcycle and as near to the center of gravity as is feasible. that Check the mounting other brackets and attachare ment hardware rigidly mounted.
- Inspect for proper ground clearance and bank angle. Inspect that the accessory does not interfere with the operation of the suspension, steering or other control operations.
- Accessories fitted to the handlebars or the front fork area can create serious stability problems. The extra weight will cause the motorcycle to be less responsive to your steering control. The weight may also cause oscillations in the front end and lead to instability problems. Accessories added to the handlebars or front fork of the machine should be as light as possible and kept to a minimum.

- Certain accessories displace the rider from his or her normal riding position. This limits the freedom of movement of the rider and may limit control ability.
- Additional electrical accessories may overload the existing electrical system. Severe overloads may damage the wiring harness or create a hazardous situation due to the loss of electrical power during the operation of the motorcycle.
- Do not pull a trailer or sidecar.
 This motorcycle is not designed to pull a trailer or sidecar.

LOADING LIMIT

AWARNING

Overloading or improper loading can cause loss of motorcycle control and an accident.

Follow loading limits and loading guidelines in this manual.

Never exceed the **GVWR** (Gross Vehicle Weight Rating) of this motorcycle. The GVWR is the combined weight of the machine, accessories, payload, rider and passenger. When selecting your accessories, keep in mind the weight of the riders as well as the weight of the accessories. The additional weight of the accessories may not only create an unsafe riding condition but may also affect the steering ease.

G.V.W.R: 449 kg (985 lbs) at the tire pressure (cold)

Front: 290 kPa

(2.90 kgf/cm², 42 psi)

Rear: 290 kPa

(2.90 kgf/cm², 42 psi)

LOADING GUIDELINES

This motorcycle is primarily intended to carry small items when you are not riding with a passenger. Follow the loading quidelines below:

- Balance the load between the left and right side of the motorcycle and fasten it securely.
- Keep cargo weight low and as close to the center of the motorcycle as possible.
- Do not attach large or heavy items to the handlebars, front forks or rear fender.
- Do not install a luggage carrier or a luggage box protruding over the tail end of the motorcycle.
- Do not carry any items that protrude over the tail end of the motorcycle.
- Check that both tires are properly inflated to the specified tire pressure for your loading conditions. Refer to page 7-38.
- Improperly loading your motorcycle can reduce your ability to balance and steer the motorcycle. You should ride at reduced speeds, less than 130 km/h (80 mph), when you are carrying cargo or have added accessories.
- Adjust suspension setting as necessary.

WARNING

Placing objects in the space behind the fairing can interfere with steering and can lose control.

Do not carry any objects in the space behind the fairing.

MODIFICATION

Modification of the vehicle or removal of original equipment may render the vehicle unsafe or illegal. Obey all applicable regulations in your area including federal and state regulations regarding environmental protection.

Suzuki's limited warranties may not cover damage caused by modifications that would change the original vehicle specifications including, without limitation, modifications of any emission-related parts such as the carburetor(s), fuel injection system components, the engine control module, air suction system components, the catalytic converter (if equipped), evaporative emission control system components (such as the carbon canister, fuel tank, fuel hoses and vapor hoses), etc.

It is strictly prohibited to modify a vehicle by installing parts that can affect emissions control, except in accordance with very specific U.S. Environmental Protection Agency and California Air Resources Board regulations.

The frame of this motorcycle is made of an aluminum alloy. Therefore, never make any modifications such as drilling or welding to the frame as it weakens the frame significantly. This could result in an unsafe vehicle operating condition and subsequent accident. Suzuki will not be responsible in any way for personal injury or damage to the motorcycle caused by frame modifications.

Bolt-on-accessories that do not modify the frame in any way may be installed, provided that the loading limit is not exceeded. For loading limit, refer to the ACCESSORY USE AND MOTORCYCLE LOADING section of the owner's manual.

WARNING

Modification to an aluminum alloy frame, such as drilling or welding, weakens the frame. This could result in an unsafe operating condition and may lead to an accident.

Never make any modifications to the frame.



INSPECTION AND MAINTENANCE

MAINTENANCE SCHEDULE	7-2
TOOLS	7-6
STEERING DAMPER MAINTENANCE	7-6
LUBRICATION POINTS	7-7
BATTERY	7-8
AIR CLEANER	
SPARK PLUGS	7-13
ENGINE OIL	7-18
ENGINE IDLE SPEED INSPECTION	
THROTTLE CABLE PLAY	
FUEL HOSE	7-25
CLUTCH	7-26
ENGINE COOLANT	7-27
DRIVE CHAIN	
BRAKES	
TIRES	
SIDE STAND/IGNITION INTERLOCK SYSTEM	7-41
FRONT WHEEL REMOVAL	
REAR WHEEL REMOVAL	
LIGHT BULB REPLACEMENT	
FUSES	7-54
CATALYTIC CONVERTER	7-56

INSPECTION AND MAINTENANCE

MAINTENANCE, REPLACE-MENT OR REPAIR OF THE EMISSION CONTROL DEVICES AND SYSTEMS MAY BE PERFORMED BY ANY MOTORCY-CLE REPAIR ESTABLISHMENT OR INDIVIDUAL USING ANY MOTORCYCLE PART WHICH HAS BEEN CERTIFIED UNDER THE PROVISIONS IN THE CLEAN AIR ACT Sec. 207 (a)(2).

MAINTENANCE SCHEDULE

It is very important to inspect and maintain your motorcycle regularly. Follow the guidelines in the chart. The intervals between periodic services in kilometers, miles and months are shown. At the end of each interval, be sure to perform the maintenance listed.

WARNING

Improper maintenance or failure to perform recommended maintenance can lead to an accident.

Keep your motorcycle in good condition. Ask your Suzuki dealer or a qualified mechanic to perform the maintenance items marked with an asterisk (*). You may perform the unmarked maintenance items by referring to the instructions in this section, if you have mechanical experience. If you are not sure how to do any of the jobs, ask your Suzuki dealer to do the maintenance.

WARNING

Exhaust gas contains carbon monoxide, a dangerous gas that is difficult to detect because it is colorless and odorless. Breathing carbon monoxide can cause death or severe injury.

Never start the engine or let it run indoors or where there is little or no ventilation.

NOTICE

Servicing electric parts with the ignition switch in the "ON" position can damage the electric parts when the electric circuit is shorted.

Turn off the ignition switch before servicing the electric parts to avoid short-circuit damage.

NOTICE

Poorly-made replacement parts can cause your motorcycle to wear more quickly and may shorten its useful life.

When replacing parts on your vehicle, use only genuine Suzuki replacement parts or their equivalent.

NOTE: The MAINTENANCE CHART specifies the minimum requirements for maintenance. If you use your motorcycle under severe conditions, perform maintenance more often than shown in the chart. If you have any questions regarding maintenance intervals, consult your Suzuki dealer or a qualified mechanic.

MAINTENANCE CHART

Interval: This interval should be judged by number of months or odometer reading, whichever comes first.


	Interval	months	2	12	24	36	48
		km	1000	6000	12000	18000	24000
Element		miles	600	4000	7500	11000	14500
Air cleaner elemen	it (🖙 7-10)		-	1	ı	R	I
* Exhaust pipe bolts and muffler bolts		Т	_	Т	-	Т	
* Valve clearance		-	-	-	-	I	
Spark plugs (7-13)		_	I	R	I	R	
Fuel hose (7-25)		-	_		I	_	
Engine oil (7-18)		R	R	R	R	R	
Engine oil filter (7-18)		R	-	_	R	_	
Throttle cable play (7-24)		I	- 1	ı	I	I	
* Throttle valve synchronization		(CA. only)	ı	1	_	I	
* Evaporative emission control system (California model only)		1	ı	1	-	1	
* PAIR (air supply) system		-	-	I	-	I	
"SUZUKI SUPER LONG LIFE COOLANT" (Blue)		Replace every 4 years or 48000 km (29000 miles)					
* Engine coolant (CF 7-27)	"SUZUKI LE LIFE COOL (Green) or engine cool than "SUZU SUPER LO COOLANT"	LANT" an ant other JKI NG LIFE	-	ı	R	-	R
Radiator hose (7-28)		-	I	ı	I	I	
Clutch fluid (7-26)		_	I	ı	I	I	
		* Replace every 2 years					
Clutch hose (7-27)		-	Ι	ı	I	I	
		* Replace every 4 years					
Drive chain (7-29)		ı	I	ı	I	I	
Drive Criairi (L. 3 1-29)			Clean and lubricate every 1000 km (600 miles)				

Interval	months	2	12	24	36	48
Interval		_				
	km	1000	6000	12000	18000	24000
Element	miles	600	4000	7500	11000	14500
* Brakes (7-33)		ı	1	ı	ı	I
Brake fluid (7-33)		-	I	I	ı	ı
		* Replace every 2 years				
Brake hose (CF 7-33)		-	1	ı	ı	I
		* Replace every 4 years				
Tires (7-37)		-	I	I	ı	ı
* Steering		I	-	I	-	ı
* Front forks (3-30)		-	-	ı	-	I
* Rear suspension (3-31)		-	-	1	-	I
* Chassis bolts and nuts		T	T	T	Т	Т
Lubrication (7-7)			Lubricate every 1000 km (600 miles)			

NOTE: I= Inspect and clean, adjust, replace or lubricate as necessary, R= Replace, T= Tighten

NOTE: (California model only) and (CA. only) means that the items or the maintenance interval is to be applied only for the California model.


TOOLS



A tool kit is provided with your motorcycle. It is located under the rear seat.

STEERING DAMPER MAINTENANCE

- 1. Keep the steering damper shaft ① clean at all times.
- 2. Wipe off any oil residue with a cloth.



NOTE:

- Do not confuse the grease-like residue on the steering damper's shaft with an oil leak. Collection of this residue is normal and is from oil seal lubricant used in the damper.
- You may also notice a sound as the damper shaft is stroked in and out. This "escaping air" type sound is normal and is made as the internal valving damps the shaft movement.


LUBRICATION POINTS


Proper lubrication is important for smooth operation and long life of each working part of your motorcycle and also for safe riding. It is a good practice to lubricate the motorcycle after a long rough ride and after getting it wet it in the rain or after washing it. Major lubrication points are indicated below.

NOTICE

Lubricating electrical switches can damage the switches.

Do not apply grease or oil to electrical switches.





- G ... Grease
- Drive chain lubricant
- 1.... Clutch lever pivot
- 2.... Side stand pivot and spring hook
- 3.... Gearshift lever pivot
- 4.... Left footrest pivot
- 5.... Drive chain
- 6.... Brake lever pivot
- 7.... Brake pedal pivot and right footrest pivot

BATTERY

The battery is a sealed type battery and requires no maintenance. Have your dealer check the battery's state of charge periodically.

NOTE:

- For charging a sealed type battery, use a battery charger applicable to a sealed type battery.
- If you cannot charge the battery, consult your authorized Suzuki dealer.

WARNING

Battery posts, terminals, and related accessories contain lead and lead compounds. Lead is harmful to your health if it gets into your blood stream.

Wash hands after handling any parts containing lead.

A WARNING

Diluted sulfuric acid from the battery can cause blindness or severe burns.

When working near the battery, use proper eye protection and gloves. Flush eyes or body with ample water and get medical care immediately if you suffer injury. Keep batteries out of reach of children.

WARNING

Batteries produce flammable hydrogen gas which can explode if exposed to flames or sparks.

Keep flames and sparks away from the battery. Never smoke when working near the battery.

WARNING

Wiping the battery with a dry cloth can cause a static electricity spark, which can start a fire.

Wipe the battery with a damp cloth to avoid static electricity build up.

NOTICE

Exceeding the maximum charging rate for the battery can shorten its life.

Never exceed the maximum charging rate for the battery.

Battery Removal

To remove the battery, follow the procedure below:

- 1. Place the motorcycle on the side stand.
- Remove the front seat by referring to the SEAT LOCK AND HELMET HOLDERS section.



- 3. Disconnect the negative (-) terminal ①.
- 4. Remove the cap. Disconnect the positive (+) terminal ②.
- 5. Remove the battery 3.

To install the battery:

- 1. Install the battery in the reverse order of removal.
- 2. Connect the battery terminals securely.

NOTE: Be sure to reset the engine rpm indicator in the instrument panel when the battery terminals are reconnected.

NOTICE

Reversing the battery lead wires can damage the charging system and the battery.

Always attach the red lead to the (+) positive terminal and the black (or black with white tracer) lead to the (-) negative terminal.


WARNING

Batteries contain toxic substances including sulfuric acid and lead. They could cause injury to humans or could damage the environment.

A used battery must be disposed of or recycled according to local law and must not be discarded with ordinary household waste. Make sure not to tip over the battery when you remove it from the vehicle. Otherwise, sulfuric acid could run out and you might be injured.

NOTE:

- Select the same type MF battery when replacing the battery.
- Recharge the battery once a month if the motorcycle is not used for a long time.



The crossed-out wheeled bin symbol (A) located on the battery label indicates that a used battery should be collected separately from ordinary household waste. The chemical symbol of "Pb" (B) indicates the battery contains more than 0.004% lead.

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health. which could otherwise be caused by inappropriate waste handling of the battery. The recycling of materials will help to conserve natural resources. For more detailed information about disposing or recycling of the used battery, consult your Suzuki dealer.

AIR CLEANER

The air cleaner element must be kept clean to provide good engine power and gas mileage. If you use your motorcycle under normal low-stress conditions, you should service the air cleaner at the intervals specified. If you ride in dusty, wet, or muddy conditions, you will need to inspect the air cleaner element much more frequently. Use the following procedure to remove the element and inspect it.

WARNING

Operating the engine without the air cleaner element in place can be hazardous. A flame can spit back from the engine to the air intake box without the air cleaner element to stop it. Severe engine damage can also occur if dirt enters the engine due to running the engine without the air cleaner element.

Never run the engine without the air cleaner element in place.


NOTICE

Failure to inspect the air cleaner element frequently if the vehicle is used in dusty, wet, or muddy conditions can damage your motorcycle. The air cleaner element can become clogged under these conditions, and engine damage may result.


Always inspect the air cleaner element after riding in severe conditions. Replace the element as necessary. If water gets in the air cleaner case, immediately clean the element and the inside of the case.

Air Cleaner Element Removal

- 1. Place the motorcycle on the side stand.
- 2. Remove the front seat by referring to the SEAT LOCK AND HELMET HOLDERS section.




3. Remove the fuel tank fitting bolts ①.




4. Remove the prop stay ② if the prop stay is equipped.


NOTE: A prop stay is available at your Suzuki dealer. The prop stay part number is 44574-35F00.




Lift the front end of the fuel tank and prop it up as shown above. Insert the crank end of the prop stay into the hole of the steering shaft.



- 6. Remove the 11 screws 3.
- 7. Remove the cover 4.



8. Remove the air cleaner element (5).




Inspect the air cleaner element condition. Replace the air cleaner element periodically.

NOTICE

Compressed air can damage the air cleaner element.

Do not blow the air cleaner element with compressed air.



10.Remove the plug and drain water and oil at the periodic maintenance interval. The air cleaner drain plug is located beneath the air cleaner box.

Installation

Reinstall the air cleaner element in reverse order of removal.

NOTICE

A torn air cleaner element will allow dirt to enter the engine and can damage the engine.

Replace the air cleaner element with a new one if it is torn. Carefully examine the air cleaner element for tears during cleaning.

NOTICE

Failure to position the air cleaner element properly can allow dirt to bypass the air cleaner element. This will cause engine damage.

Be sure to properly install the air cleaner element.

NOTE: Be careful not to spray water on the air cleaner box when cleaning the motorcycle.

Reinstall the fuel tank.

NOTE: Check that the fuel tank drain hose and breather hose are not bent before reinstalling the fuel tank

SPARK PLUGS

Your motorcycle comes equipped with an NGK CR9EIA-9 DENSO IU27D spark plugs. To determine if the standard spark plug is right for your usage, check the color of the plug's porcelain center electrode insulator after motorcycle operation. liaht brown color indicates that the plug is correct. A white or dark insulator indicates that the engine may need adjustment, or another plug type may be needed. Consult vour Suzuki dealer or a qualified mechanic if your plug insulator is not a light brown color.

NOTICE

An improper spark plug may have an incorrect fit or inappropriate heat range for your engine. This may cause severe engine damage which may not be covered under warranty.

Use one of the spark plugs listed or their equivalent. Consult your Suzuki dealer if you are not sure which spark plug is correct for your type of usage.

Plug Replacement Guide


NGK	DENSO	REMARKS
CR8EIA-9	IU24D	If the standard plug is apt to get wet, replace with this plug.
CR9EIA-9	IU27D	Standard
CR10EIA-9	CR10EIA-9 IU31D If the plug is overh with the	

NOTE: If the above-named plugs are not available, consult your Suzuki dealer.


NOTE: This motorcycle uses a resistor-type spark plug to avoid jamming electronic parts. Improper spark plug selection may cause electronic interference with your motorcycle's ignition system, resulting in motorcycle performance problems. Use only the recommended spark plugs.


Spark Plug Removal

1. Lift the fuel tank by referring to the AIR CLEANER section.




2. Remove the bolt 1.







4. Disconnect the air cleaner sensor assembly ③. Disconnect the coupler ④. Pull out the tube ⑤.



- 5. Pull out the tubes 6, 7.
- 6. Remove the air cleaner box.



7. Release the coupler locks and disconnect the couplers from the ignition coils.




8. Pull off the ignition coils.

NOTICE

Improper removal of ignition coils can damage the ignition coils.

Pull off the ignition coils with your hand. Do not use pliers.




9. Remove the spark plug with a spark plug wrench.

NOTICE

Dirt can damage the moving engine parts of your motorcycle if it enters an open spark plug hole.

Cover the spark plug hole while the spark plug is out of the hole.

Spark Plug Inspection



Measure the spark plug gap (A) with a wire type feeler gauge. The standard spark plug gap is 0.8 – 0.9 mm (0.031 – 0.035 in). If the measured spark plug gap is out of standard range, replace the spark plug with a new one.

Installation

NOTICE

Improper installation of the spark plug can damage your motorcycle. An overly-tight or cross-threaded spark plug will damage the aluminum threads of the cylinder head.

Carefully turn the spark plug by hand into the threads. If the spark plug is new, tighten it with a wrench about 1/2 turn past finger tight. If you are reusing the old spark plug, tighten it with a wrench about 1/8 turn past finger tight.

NOTICE

Dirt can damage the moving engine parts of your motorcycle if it enters an open spark plug hole.

Cover the spark plug hole while the spark plug is out of the hole.

Reinstall the air cleaner box and fuel tank in the reverse order of removal.

NOTE: Check that the fuel tank drain hose and breather hose are not bent before reinstalling the fuel tank.


ENGINE OIL

Engine life depends on oil amount and quality. Daily oil level checks and periodic changes are two of the most important maintenance items to be performed.

Engine Oil Level Check

Check the engine oil level as follows:

- 1. Place the motorcycle on level ground on the side stand.
- 2. Start the engine and allow it to idle for three minutes.
- 3. Stop the engine and wait three minutes.



4. Hold the motorcycle vertically and check the oil level through the oil level inspection window on the right side of the engine. The engine oil level should be between the "L" (low) and the "F" (full) lines.

NOTICE

Operating the motorcycle with too little or too much oil can damage the engine.

Place the motorcycle on level ground. Check the oil level with the engine oil inspection window before each use of the vehicle. Be sure the engine oil level is always above the "L" (low) line and not higher than the "F" (full) line.


Engine Oil and Filter Change

Change the engine oil and oil filter at the scheduled times. The engine should always be warm when the oil is changed so the oil will drain easily. The procedure is as follows:

1. Place the motorcycle on the side stand.



2. Remove the oil filler cap ①.



3. Remove the drain plug ② and gasket ③ from the bottom of the engine and drain the engine oil into a drain pan.

A CAUTION

Hot engine oil and exhaust pipes can burn you.

Wait until the engine oil drain plug and exhaust pipes cool before draining oil.

A CAUTION

A hot muffler can burn you. The muffler will be hot enough to burn you for some time after stopping the engine.

Wait until the muffler cools to avoid burns.

WARNING

Children and pets may be harmed by swallowing new or used oil. Repeated, prolonged contact with used engine oil may cause skin cancer. Brief contact with oil may irritate skin.

Keep new and used oil and used oil filters away from children and pets. To minimize your exposure to used oil, wear a long-sleeve shirt and moisture-proof gloves (such as dishwashing gloves) when changing oil. If oil contacts your skin, wash thoroughly with soap and water. Launder any clothing or rags if wet with oil. Recycle or properly dispose of used oil and filters.


NOTICE


Turning the engine while draining the engine oil will cause oil film shortage and adversely affect the engine.

Do not use the electric starter switch during engine oil replacement work.


NOTE:

- Recycle or properly dispose of used oil.
- Before starting the work, check that there is not any dust, mud, or foreign object inside the oil jug or on the oil filter mounting surface.






Remove the bolts and fasteners.




5. Remove the fasteners.




6. Remove the bolts and hooks of the right fairing ④.




Available from Suzuki dealer Oil filter wrench (Part No. 09915-40620)



7. Turn the oil filter ⑤ counterclockwise and remove it with a Suzuki "cap type" oil filter wrench or a "strap type" filter wrench of the proper size.



8. Wipe off the mounting surface 6 on the engine where the new filter will be seated with a clean rag.




- Smear a little engine oil around the rubber gasket of the new oil filter.
- 10.Screw the new filter by hand until the filter gasket contacts the mounting surface (small resistance will be felt).

NOTICE

Failure to use an oil filter with the correct design and thread specifications can damage your motorcycle's engine.

Be sure to use a genuine Suzuki oil filter or an equivalent one designed for your motorcycle.

NOTE: To tighten the oil filter properly, it is important to accurately identify the position at which the filter gasket first contacts the mounting surface.



Tighten the filter 2 turns or to specified torque.

11.Mark the top dead center position on the "cap type" filter wrench or on the oil filter. Use an oil filter wrench to tighten the filter 2 turns or to specified torque.

Oil filter tightening torque: 20 N·m (2.0 kgf-m, 14.5 lbf-ft)

12.Replace the drain plug gasket
③ with a new one. Reinstall the drain plug ② and gasket
③. Tighten the plug securely with a torque wrench. Pour 3300 ml (3.5 US qt) of new engine oil through the filler hole and install the filler cap. Be sure to always use the specified engine oil described in the FUEL, ENGINE OIL AND COOLANT RECOMMENDATIONS section.

Drain plug tightening torque: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

NOTE: About 3100 ml (3.3 US qt) of oil will be required when changing oil only.

NOTICE

Engine damage may occur if you use oil that does not meet Suzuki's specifications.

Be sure to use the oil specified in the FUEL, ENGINE OIL AND COOLANT RECOMMENDATIONS section.

- 13.Start the engine (while the motorcycle is outside on level ground) and allow it to idle for three minutes.
- 14. Turn the engine off and wait approximately three minutes. Recheck the oil level on the engine oil inspection window while holding the motorcycle vertically. If it is lower than the "L" line, add oil until the oil level is between the "L" line and the "F" line. Inspect the area around the drain plug and oil filter for leaks.


NOTE: If you do not have a proper oil filter wrench, have your Suzuki dealer perform this service.


ENGINE IDLE SPEED INSPECTION

Inspect the engine idle speed. The engine idle speed should be 1050 - 1250 r/min when the engine is warm.

NOTE: If the engine idle speed is not within the specified range, ask your Suzuki dealer or a qualified mechanic to inspect and repair the motorcycle.

THROTTLE CABLE PLAY





To adjust the cable play:


- 1. Remove the boot 1.
- 2. Loosen the lock nut 2.
- 3. Turn the adjuster ③ so that the throttle grip has 2.0 4.0 mm (0.08 0.16 in) play.
- 4. Tighten the lock nut 2.
- 5. Reinstall the boot 1.

WARNING

Inadequate throttle cable play can cause engine speed to rise suddenly when you turn the handlebars. This can lead to loss of control and an accident.


Adjust the throttle cable play so that engine idle speed does not rise due to handlebar movement.

Throttle Cable Boots




The throttle cable has a boots. Check that the boots are fit securely. Do not apply water directly to the boots when washing. Wipe off dirt from the boots with a wet cloth when the boots are dirty.

FUEL HOSE



Inspect the fuel hose for damage and fuel leakage. If any defects are found, the fuel hose must be replaced.

CLUTCH



The clutch release mechanism of this motorcycle is operated by hydraulic pressure. There is no adjustment needed on the clutch release system because the system is self adjusting. However, inspect the following each time before driving to make sure that the system is in good condition and functioning properly.

- Fluid level in the reservoir to be above "LOWER" line.
- No fluid leakage.
- Smooth and sure action of clutch lever.

WARNING

The use of any fluid except DOT4 fluid from a sealed container can damage the clutch system and lead to an accident.

Clean filler cap before removing. Use only DOT4 fluid from a sealed container. Never use or mix with different types of fluid.

A WARNING

Fluid is harmful or fatal if swallowed, and harmful if it comes in contact with skin or eyes. Solution can be poisonous to animals.

If fluid is swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. If fluid gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Keep out of the reach of children and animals.

NOTICE

Spilled fluid can damage painted surfaces and plastic parts.


Be careful not to spill any fluid when filling the fluid reservoir. Wipe spilled fluid up immediately.

NOTE: SUZUKI highly recommends the use of ECSTAR brand clutch fluid. ECSTAR has been specially formulated for your SUZUKI product and contributes to the desired motorcycle performance and ideal riding experience.

Clutch Hose Inspection

Inspect the clutch hoses and hose joints for cracks or clutch fluid leakage. If any defects are found, ask your Suzuki dealer to replace the clutch hose with a new one.

ENGINE COOLANT Coolant level




The engine coolant solution should be between the "F" (full) and the "L" (low) level lines on the engine coolant reservoir. If the level is lower than the "L" level line, bring it up to the "F" level by adding specified engine coolant.

To add specified engine coolant:

- 1. Place the motorcycle on the side stand.
- Remove the right fairing by referring to the ENGINE OIL section.

NOTE:

- Check the coolant level when the engine is cold.
- If the engine coolant reservoir is empty, check the radiator coolant level.



 Remove the filler cap and add specified engine coolant through the filler hole until it reaches the "F" line. Refer to the FUEL, ENGINE OIL AND COOLANT RECOMMENDA-TIONS section.

WARNING

Engine coolant is harmful or fatal if swallowed or inhaled. Solution can be poisonous to animals.

Do not drink antifreeze or coolant solution. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. Avoid inhaling mist or hot vapors; if inhaled, remove to fresh air. If coolant gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Keep out of the reach of children and animals.

NOTE: Adding only water will dilute the engine coolant and reduce its effectiveness. Add specified engine coolant.

Radiator Hose Inspection

Inspect the radiator hoses for cracks, damage or engine coolant leakage. If any defects are found, ask your Suzuki dealer to replace the radiator hose with a new one.

DRIVE CHAIN

This motorcycle has an endless drive chain constructed from special materials. It does not use a master link. We recommend that you take your motorcycle to an authorized Suzuki dealer if the drive chain needs to be replaced.

The condition and adjustment of the drive chain should be checked each day before you ride. Always follow the guidelines for inspecting and servicing the chain.

▲ WARNING

Riding with the chain in poor condition or improperly adjusted can lead to an accident.


Inspect, adjust, and maintain the chain properly before each ride, according to the instructions in this section.

Inspecting the Drive Chain

When inspecting the chain, look for the following:

- Loose pins
- · Damaged rollers
- Dry or rusted links
- · Kinked or binding links
- Excessive wear
- · Improper chain adjustment

If you find anything wrong with the drive chain condition or adjustment, correct the problem if you know how. If necessary, consult your authorized Suzuki dealer or a qualified mechanic.



Damage to the drive chain means that the sprockets may also be damaged. Inspect the sprockets for the following:

- Excessively worn teeth
- Broken or damaged teeth
- Loose sprocket mounting nuts

If you find any of these problems with your sprocket, consult your Suzuki dealer or a qualified mechanic.

NOTE: The two sprockets should be inspected for wear when a new chain is installed and replace them if necessary.

WARNING

Improperly installing a replacement chain, or using a joint-clip type chain, can be hazardous. An incompletely riveted master link, or a joint-clip type master link, may come apart and cause an accident or severe engine damage.

Do not use a joint-clip type chain. Chain replacement requires a special riveting tool and a high-quality, non-joint-clip type chain. Ask an authorized Suzuki dealer or a qualified mechanic to perform this work.

Drive Chain Cleaning and Oiling

- Remove dirt and dust from the drive chain. Be careful not to damage the seal ring.
- Clean the drive chain with a sealed drive chain cleaner, or water and neutral detergent.

NOTICE

Cleaning the drive chain improperly can damage seal rings and ruin the drive chain.

- Do not use a volatile solvent such as paint thinner, kerosene and gasoline.
- Do not use a high pressure cleaner to clean the drive chain.
- Do not use a wire brush to clean the drive chain.
- 3. Use a soft brush to clean the drive chain. Be careful not to damage the seal ring even though using a soft brush.
- 4. Wipe off water and neutral detergent.
- Lubricate with a motorcycle sealed drive chain lubricant or high viscosity oil (#80 – 90).

NOTICE

Some drive chain lubricant contains solvents and additives which could damage the seal rings in the drive chain.

Use sealed drive chain lubricant which is specifically intended for use with sealed drive chains.

- 6. Lubricate both front and back plates of the drive chain.
- Wipe off excess lubricant after lubricating all around the drive chain.

Drive Chain Adjustment



20 – 30 mm (0.8 – 1.2 in)

Inspect the drive chain slack before each use of the motorcycle. Place the motorcycle on the side stand. The drive chain should be adjusted for 20 – 30 mm (0.8 – 1.2 in) of slack, as shown.

WARNING

Too much chain slack can cause the chain to come off the sprockets, resulting in an accident or serious damage to the motorcycle.

Inspect and adjust the drive chain slack before each use.


To adjust the drive chain, follow the procedure below:

A CAUTION

A hot muffler can burn you. The muffler will be hot enough to burn you for some time after stopping the engine.

Wait until the muffler cools before adjusting the drive chain.

1. Place the motorcycle on the side stand.




- 2. Loosen the axle nut 1.
- 3. Loosen the right and left lock nut ②.
- 4. Turn the right and left adjuster bolts ③ until the chain has 20 30 mm (0.8 1.2 in) of slack halfway between the engine sprocket and rear sprocket.
- 5. At the same time that the chain is being adjusted, the rear sprocket must be kept in perfect alignment with the front sprocket. To assist you in performing this procedure, there are reference marks 4 on the swingarm and each chain adjuster which are to be aligned with each other and to be used as a reference from one side to the other.
- 6. Tighten the axle nut 1 securely.
- Recheck the chain slack after tightening and readjust if necessary.
- 8. Tighten the right and left lock nut (2).

Rear axle nut tightening torque: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)

NOTE: Do not adjust the drive chain beyond the adjustable range 4. Replace the drive chain before the drive chain exceeds the limit.

Sprocket Cover Protector



Remove the sprocket cover and inspect the sprocket cover protector for wear and damage when adjusting drive chain. If the sprocket cover protector is worn or cracked, replace it with a new one.

BRAKES

This motorcycle has front and rear disk brakes.

WARNING

Failure to properly inspect and maintain your motorcycle's brake systems can increase your chance of having an accident.


Be sure to inspect the brakes before each use according to the INSPECTION BEFORE RIDING section. Always maintain your brakes according to the MAINTENANCE SCHED-ULE.

NOTE: Operating in mud, water, sand or other extreme conditions can cause accelerated brake wear. If you operate your motorcycle under these conditions, the brakes must be inspected more often than recommended in the MAINTENANCE SCHEDULE.

Brake Hose Inspection

Inspect the brake hoses and hose joints for cracks, damage or brake fluid leakage. If any defects are found, ask your Suzuki dealer to replace the brake hose with a new one.

Brake Fluid



Check the brake fluid level in both the front and rear brake fluid reservoirs. If the level in either reservoir is below the lower mark, inspect for brake pad wear and leaks.

WARNING

Brake fluid will gradually absorb moisture through the brake hoses. Brake fluid with high water content lowers the boiling point and can cause brake system (including ABS) malfunction due to corrosion of brake components. Boiling brake fluid or brake system (including ABS) malfunction could result in an accident.

Replace the brake fluid every two years to maintain braking performance.

WARNING

The use of any fluid except DOT4 brake fluid from a sealed container can damage the brake system and lead to an accident.

Clean filler cap before removing. Use only DOT4 brake fluid from a sealed container. Never use or mix with different types of brake fluid.

WARNING

Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with skin or eyes. Solution can be poisonous to animals.

If brake fluid is swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. If brake fluid gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Keep out of the reach of children and animals.

NOTICE


Spilled brake fluid can damage painted surfaces and plastic parts.

Be careful not to spill any fluid when filling the brake fluid reservoir. Wipe spilled fluid up immediately.


NOTE: SUZUKI highly recommends the use of ECSTAR brand brake fluid. ECSTAR has been specially formulated for your SUZUKI product and contributes to the desired motorcycle performance and ideal riding experience.


Brake Pads

FRONT



RFAR





Inspect the front and rear brake pads to see if they are worn down to the grooved wear limit line ①. If a front or rear pad is worn to the grooved wear limit line, both front or both rear pads must be replaced with new ones. After replacing either the front or rear brake pads, the brake lever or pedal must be pumped several times. This will extend the pads to their proper position.

WARNING

Failure to inspect and maintain the brake pads and replace them when recommended can increase your chance of having an accident.

If you need to replace brake pads, have your Suzuki dealer do this work. Inspect and maintain the brake pads as recommended.

WARNING

If you ride this motorcycle after brake system repair or brake pad replacement without pumping the brake lever/pedal, you may get poor braking performance which could result in an accident.

After brake system repair or brake pad replacement, pump the brake lever/pedal several times until brake pads are pressed against the brake disks and proper lever/pedal stroke and firm feel are restored.

NOTE: Do not squeeze/depress the brake lever/pedal when the pads are not in their positions. It is difficult to push the pistons back and brake fluid leakage may result.


WARNING

Replacing only one of the two brake pads can result in uneven braking action and can increase your chance of having an accident.

Always replace both pads together.

Rear Brake Pedal Adjustment

The rear brake pedal position must be properly adjusted at all times or the disk brake pads will rub against the disk causing damage to the pads and to the disk surface. Adjust the brake pedal position in the following manner:




- Loosen the lock nut ①, and turn the push rod ② to locate the pedal 50 60 mm (2.0 2.4 in) below the top face of the footrest.
- 2. Retighten the lock nut ① to secure the push rod ② in the proper position.

NOTICE

An incorrectly adjusted brake pedal may force brake pads to continuously rub against the disk, causing damage to the pads and disk.

Follow the steps in this section to adjust the brake pedal properly.

Rear Brake Light Switch



To adjust the brake light switch, hold the switch body and turn the adjuster so that the brake light will come on just before a pressure rise is felt when the brake pedal is depressed.

TIRES

WARNING

The tires on your motorcycle form the crucial link between your motorcycle and the road. Failure to take the precautions below may result in an accident due to tire failure.

- Check tire condition and pressure before each ride, and adjust pressure if necessary.
- Avoid overloading your motorcycle.
- Replace a tire when worn to the specified limit, or if you find damage such as cuts or cracks.
- Always use the size and type of tires specified in this owner's manual.
- Balance the wheel after tire installation.
- Read this section of the owner's manual carefully.

WARNING

Failure to perform break-in of the tires could cause tire slip and loss of control, which could result in an accident.

Use extra care when riding on new tires. Perform proper break-in of the tires referring to the BREAK-IN section of this manual and avoid hard acceleration, hard cornering, and hard braking for the first 100 miles (160 km).

Tire Pressure and Loading

Proper tire pressure and proper tire loading are important factors. Overloading your tires can lead to tire failure and loss of vehicle control.

Check tire pressure each day before you ride, and be sure the pressure is correct for the vehicle load according to the table below. Tire pressure should only be checked and adjusted before riding, since riding will heat up the tires and lead to higher inflation pressure readings.

Under-inflated tires make smooth cornering difficult, and can result in rapid tire wear. Over-inflated tires cause a smaller amount of tire to be in contact with the road, which can contribute to skidding and loss of control.

NOTE: When you detect drops in tire pressure, check the tire for nails or other punctures, or a damaged wheel rim. Tubeless tires sometimes lose pressure gradually when punctured.


LOAD	SOLO RIDING	DUAL RIDING
FRONT	290 kPa 2.90 kgf/cm² 42 psi	290 kPa 2.90 kgf/cm² 42 psi
REAR	290 kPa 2.90 kgf/cm² 42 psi	290 kPa 2.90 kgf/cm² 42 psi

Tire Condition and Type

Tire condition and tire type affect motorcycle performance. Cuts or cracks in the tires can lead to tire failure and loss of motorcycle control. Worn tires are susceptible to puncture failures and subsequent loss of motorcycle control. Tire wear also affects the tire profile, changing motorcycle handling characteristics.



Check the condition of your tires each day before you ride. Replace tires if tires show visual evidence of damage, such as cracks or cuts, or if tread depth is less than 1.6 mm (0.06 in) front, 2.0 mm (0.08 in) rear.



Triangle mark

NOTE: The "Triangle mark" mark indicates the place where the wear bars are molded into the tire. When the wear bars contact the road, it indicates that the tire wear limit has been reached.

Whenever you replace a tire, use a tire of the size and type listed below. If you use a different size or type of tire, motorcycle handling may be adversely affected, possibly resulting in loss of motorcycle control.

	FRONT	REAR
SIZE	120/70ZR17M/C (58W)	190/50ZR17M/C (73W)
TYPE	BRIDGESTONE BT015F RADIAL M	BRIDGESTONE BT015R RADIAL M

Always balance the wheel after repairing a puncture or replacing the tire. Proper wheel balance is important to avoid variable wheel-to-road contact, and to avoid uneven tire wear.

WARNING

An improperly repaired, installed, or balanced tire can cause loss of control and an accident, or can wear out sooner.


- Ask your Suzuki dealer or a qualified mechanic to perform tire repair, replacement, and balancing because proper tools and experience are required.
- Install tires according to the rotation direction shown by arrows on the sidewall of each tire.

WARNING

Failure to follow the instructions below for tubeless tires may result in an accident due to tire failure. Tubeless tires require different service procedures than tube tires.

- Tubeless tires require an airtight seal between the tire bead and wheel rim. Special tire irons and rim protectors or a specialized tire mounting machine must be used for removing and installing tires to prevent tire or rim damage which could result in an air leak.
- Repair punctures in tubeless tires by removing the tire and applying an internal patch.
- Do not use an external repair plug to repair a puncture since the plug may work loose as a result of the cornering forces experienced by a motorcycle tire.
- After repairing a tire, do not exceed 80 km/h (50 mph) for the first 24 hours, and do not exceed 130 km/h (80 mph) thereafter. This is to avoid excessive heat build-up which could result in a tire repair failure and tire deflation.
- Replace the tire if it is punctured in the sidewall area, or if a puncture in the tread area is larger than 6 mm (3/16 in). These punctures cannot be repaired adequately.

SIDE STAND/IGNITION INTERLOCK SYSTEM



Check the side stand/ignition interlock system for proper operation as follows:

- 1. Sit on the motorcycle in the normal riding position, with the side stand up.
- 2. Shift into first gear, hold the clutch in, and start the engine.
- 3. While continuing to hold the clutch in, move the side stand to the down position.

If the engine stops running when the side stand is moved to the down position, then the side stand/ignition interlock system is working properly. If the engine continues to run with the side stand down and the transmission in gear, then the side stand/ignition interlock system is not workproperly. your ing Have motorcycle inspected bν an authorized Suzuki dealer or a qualified service mechanic.


WARNING

If the side stand/ignition interlock system is not working properly, it is possible to ride the motorcycle with the side stand in the down position. This may interfere with rider control during a left turn and could cause an accident.


Check the side stand/ignition interlock system for proper operation before riding. Check that the side stand is returned to its full up position before starting off.

FRONT WHEEL REMOVAL

1. Place the motorcycle on the side stand.




2. Remove the front wheel speed sensor by removing the mounting bolt.




3. Remove both brake calipers from the front forks by removing 2 mounting bolts ① on each of the calipers.

NOTE: Never squeeze the front brake lever with the caliper removed. It is very difficult to force the pads back into the caliper assembly and brake fluid leakage may result.



- 4. Remove the bolt 2.
- 5. Loosen the axle holder bolts 3.




- 6. Loosen the axle holder bolts 4.
- Place an accessory service stand or equivalent under the swingarm to help stabilize the rear end.
- Carefully position a jack under the exhaust pipe and raise until the front wheel is slightly off the ground.


NOTICE

Improper jacking may cause damage to the fairing or oil filter.


Do not place the jack under the lower part of the fairing or the oil filter when jacking up the motorcycle.




9. Draw out the axle shaft.



- 10. Slide the front wheel forward.
- 11.Put the new wheel in place and insert the axle shaft.
- 12.Remove the jack and service stand.



- 13. Hold the shaft and tighten the bolt ⑤ to the specified torque.
- 14. Tighten the axle holder bolts 6 to the specified torque.
- 15. Move the steering up and down several times to seat the axle shaft.



- 16. Tighten the axle holder bolts $\widehat{\mathcal{T}}$ to the specified torque.
- 17. Reinstall the brake calipers.
- 18.After installing the wheel, apply the brake several times to restore the proper lever stroke.

WARNING

Failure to extend brake pads after installing the wheel can cause poor braking performance and may result in an accident.

Before riding, "pump" the brake lever repeatedly until brake pads are pressed against the brake disks and proper lever stroke and firm feel are restored. Also check that the wheel rotates freely.

WARNING

Installing the front wheel in the reverse direction can be hazardous. The tire for this motorcycle is directional. Therefore, the motorcycle may have unusual handling if the wheel is installed incorrectly.

Install the front wheel so that the tire rotates in the specified direction, as indicated by the arrow on the sidewall of the tire.

WARNING

If the bolts and nuts are not properly tightened, the wheel can come off, causing an accident.

Be sure to tighten the bolts and nuts to the specified torque. If you do not have a torque wrench or do not know how to use one, ask your authorized Suzuki dealer to check the bolts and nuts.

Front axle tightening torque: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)

Front axle holder bolt tightening torque: 23 N·m (2.3 kgf-m, 16.5 lbf-ft)

Front brake caliper mounting bolt tightening torque: 39 N·m (3.9 kgf-m, 28.0 lbf-ft)

REAR WHEEL REMOVAL

A CAUTION

A hot muffler can burn you.


Wait until the muffler cools before removing the axle nut.

NOTICE


Removing the rear wheel without use of an accessory stand can result in your motorcycle falling over and being damaged.

Do not attempt roadside removal of the rear wheel. Only remove the rear wheel at a properly equipped servicing facility using an accessory service stand.


1. Place the motorcycle on the side stand.




Remove the rear wheel speed sensor by removing the mounting bolt.




- 3. Remove the axle nut 1.
- 4. Place an accessory service stand or an equivalent stand under the swingarm to lift the rear wheel slightly off the ground.
- Loosen the right and left lock nut ②. Turn the right and left chain adjuster bolts ③ clockwise.




6. Draw out the axle shaft.



With the wheel moved forward, remove the chain from the sprocket.



8. Remove the rear assembly 4.



9. Pull the rear wheel assembly rearward.

NOTE: Never depress the rear brake pedal with the rear wheel removed. It is very difficult to force the pads back into the caliper assembly.

- 10.To replace the wheel reverse the complete sequence listed above.
- 11. Adjust the drive chain slack.
- 12.After installing the wheel, apply the brake several times and then check that the wheel rotates freely.

WARNING

Failure to adjust the drive chain and failure to torque bolts and nuts properly could lead to an accident.

- After installing the rear wheel, adjust the drive chain as described in the DRIVE CHAIN ADJUSTMENT section.
- Torque bolts and nuts to the proper specifications. If you are not sure of the proper procedure, have your authorized Suzuki dealer or a qualified mechanic do this.

Rear axle nut tightening torque: 100 N·m (10.0 kgf-m, 72.5 lbf-ft)

A WARNING

Failure to extend brake pads after installing the wheel can cause poor braking performance and may result in an accident.

Before riding, "pump" the brake pedal repeatedly until brake pads are pressed against the brake disks and proper pedal stroke and firm feel are restored. Also check that the wheel rotates freely.

LIGHT BULB REPLACEMENT

The wattage rating of each bulb is shown in the following chart. When replacing a burned-out bulb, always use the same wattage rating according to the following chart.

NOTICE

Failure to use a light bulb with the correct wattage rating can overload the electrical system of your motorcycle or cause the bulb to burn out sooner.


Use only the light bulbs shown in the chart as replacement bulbs.

Headlight	12V 55W (H7) Low beam 12V 65W (H9) High beam
Position light	12V 5W × 2
Front turn signal light	12V 21W × 2
Rear turn signal light	12V 21W × 2
License plate light	12V 5W


HEADLIGHT AND POSITION LIGHT

To replace the headlight bulbs and position light bulb, perform the following steps:


Instrument Panel Removal




 Remove the bolt and fasteners. Remove the lower meter panel ① by unhooking the hooks.



2. Remove the fasteners. Remove the upper meter panel ② by unhooking the hooks.




3. Remove the bolts. Unhook the hooks to lift the instrument panel ③.




- Disconnect the coupler and remove the instrument panel 3.
- 5. To install the instrument panel assembly, reverse the complete sequence listed above.


Upper Light Bulb



1. Disconnect the socket ① from the headlight and remove the rubber cap ②.



Unhook the bulb holder spring
 and pull out the bulb socket
 .




3. Pull off the bulb ⑤ from the socket ④.

NOTICE

The headlight bulb's life may be shortened by oil from your fingers if you touch it.

When replacing the headlight bulb, be careful not to touch the glass. Grasp the new bulb with a clean cloth.

Lower Light Bulb






Disconnect the coupler ①. Turn the bulb ② counterclockwise and remove it.

NOTICE


The headlight bulb's life may be shortened by oil from your fingers if you touch it.

When replacing the headlight bulb, be careful not to touch the glass. Grasp the new bulb with a clean cloth.

Position Light




1. Pull out the socket.




2. Pull off the bulb from the socket.

Headlight Beam Adjustment

The headlight beam can be adjusted both up and down or right and left if necessary.



Remove the fasteners. Remove the under cover.




To adjust the beam up and down: Turn the adjuster ① clockwise or counterclockwise.

To adjust the beam right and left: Turn the adjuster ② clockwise or counterclockwise.

FRONT TURN SIGNAL LIGHT

To replace the turn signal light bulb, follow these directions.

 Remove the lower meter panel and upper meter panel by referring to the HEADLIGHT AND POSITION LIGHT section.



2. Remove the bolt and screw. Remove the upper right and left panel by unhooking the hooks.




3. Turn the socket counterclockwise and remove it.



- 4. Push in on the bulb, turn it to the left, and pull it out.
- 5. To fit the replacement bulb, push it in and twist it to the right while pushing.

REAR TURN SIGNAL LIGHT

To replace the turn signal light bulb, follow these directions.



1. Remove the screw ①.



2. Turn the socket counterclockwise and remove it.



- 3. Push in on the bulb, turn it to the left, and pull it out.
- 4. To fit the replacement bulb, push it in and twist it to the right while pushing.


NOTICE

Overtightening the screws when reinstalling the lens may cause the lens to crack.


Tighten the lens screws only until they are snug.

LICENSE PLATE LIGHT


To replace the license plate light bulb, follow the procedure steps:



1. Remove the nuts 1.



Remove the screws ② and take off the cover with the lens ③.



- 3. Push in on the bulb, twisting it to the left, and pull it out.
- 4. To fit the replacement bulb, push it in and twist it to the right while pushing.

FUSES

If something electrical on your motorcycle stops working, the first thing you should check for is a blown fuse. The electrical circuits on the motorcycle are protected from overload by fuses in the circuits.

If a blown fuse is found, then the electrical problem must be inspected and repaired before replacing the blown fuse with a new fuse. Consult your Suzuki dealer for the electrical system check and repair.


AWARNING

Replacing a fuse with a fuse that has an incorrect amperage rating or substitute, e.g. aluminum foil or wire, may cause serious damage to the electrical system and possibly fire. Always replace a blown fuse with a fuse of the same amperage rating.

If the new fuse blows in a short time, the electrical problem may not be fixed. Have your motorcycle inspected immediately by your Suzuki dealer.



The main fuse is located under the front seat. To access the fuse, remove the seat by referring to the SEAT LOCK AND HELMET HOLDERS section. One 30A spare fuse is located inside the fuse box cover.



The fuses are located behind the upper left panel under the left handlebar. Remove the upper left panel by referring to the FRONT TURN SIGNAL LIGHT section.

Fuse box ① has HEAD-HI, HEAD-LO, FUEL, IGNITION, SIGNAL and FAN.L fuses.

Fuse box 2 has FAN.R fuse.

Fuse box 3 has ABS fuse.

Fuse List

- 30A MAIN fuse protects all electrical circuits.
- 10A HEAD-HI fuse protects the headlight high beam and speedometer.
- 10A HEAD-LO fuse protects the headlight low beam.
- 15A IGNITION fuse protects the cooling fan relay, ignition coils, starter relay, fuel pump relay, solenoid, ECM, oxygen sensor, side stand relay and *canister purge solenoid.
- 10A SIGNAL fuse protects the turn signal lights, position lights, taillight, stop lamp, license light, speedometer and horn.
- 10A FUEL fuse protects the speedometer, fuel injectors, fuel pump and ECM.
- 15A FAN.R fuse protects the cooling fan motor R.
- 15A FAN.L fuse protects the cooling fan motor L.
- 30A ABS fuse protects the ABS system.
- * For California

CATALYTIC CONVERTER

The purpose of the catalytic converter is to minimize the amount of harmful pollutants in your motorcycle's exhaust. Use of leaded fuel in motorcycles equipped with catalytic converters is prohibited because lead deactivates the pollutant-reducing components of the catalyst system.

The converter is designed to last the life of the motorcycle under normal usage and when unleaded fuel is used. Not special maintenance is required on the con-However. verter. it is important to keep the engine properly tuned. Engine misfiring, which can result from an improperly tuned engine, may cause overheating of the catalyst. This may result in permanent heat damage to the catalyst and other motorcycle components.

WARNING

If you park or operate the motorcycle in areas where there are combustible materials such as dry grass or leaves, these materials may come in contact with the catalytic converter or other hot exhaust components. This can cause a fire.

Avoid parking or operating your vehicle in areas with any combustible materials.

NOTICE

Improper motorcycle operation can cause catalyst or other motorcycle damage.

To avoid damage to the catalyst or other related components, you should take the following precautions:

- Maintain the engine in the proper operating condition.
- In the event of an engine malfunction, particularly one involving engine misfire or other apparent performance loss, stop riding the motorcycle and turn off the engine and have the motorcycle serviced promptly.
- Do not shut off the engine or interrupt the ignition when the transmission is in gear and the motorcycle is in motion.
- Do not try to start the engine by pushing the motorcycle or by coasting down a hill.
- Do not idle the engine with any spark plug wires disconnected or removed, such as during diagnostic testing.
- Do not idle the vehicle for prolonged periods if idling seems rough or there are other malfunctions.
- Do not allow the fuel tank to get near the empty level.



TROUBLESHOOTING

FUEL SUPPLY CHECK	8-2
IGNITION SYSTEM CHECK	8-3

TROUBLESHOOTING

This troubleshooting guide is provided to help you find the cause of some common complaints.

NOTICE

Improper repairs or adjustments may damage the motorcycle instead of fixing it. Such damage may not be covered under warranty.

If you are not sure about the proper action, consult your Suzuki dealer about the problem.


COMPLAINT: Engine is hard to start or does not start at all.

FUEL SUPPLY CHECK

If the fuel injection indicator displays "FI", showing signs of trouble in the fuel injection system, take your machine to an authorized Suzuki dealer. Refer to the "INSTRUMENT PANEL" section for an explanation of the fuel injection system indicator.

IGNITION SYSTEM CHECK

1. Remove the spark plug and reattach it to the ignition coil.



- 2. Put the engine stop switch in the "○" position and the ignition switch in the "ON" position. While holding a spark plug with its base firmly against the engine, push the electric starter switch. If the ignition system is operating properly, a blue spark should jump across the spark plug gap.
- If there is no spark, clean the spark plug. Replace it if necessary. Retry the above procedure with the cleaned spark plug or a new one.
- 4. If there is still no spark, take your motorcycle to an authorized Suzuki dealer.

WARNING

Performing the spark test improperly can be hazardous. You could get a high voltage electrical shock if you are not familiar with this procedure.

Do not perform this check if you are not familiar with the procedure. Do not point the spark plug near the spark plug hole during this test. Do not perform this test if you have a heart condition or wear a pacemaker.

COMPLAINT: Engine stalls.

- 1. Make sure there is enough fuel in the fuel tank.
- If the fuel injection indicator displays "FI", showing signs of trouble in the fuel injection system, take your machine to an authorized Suzuki dealer. Refer to the "INSTRUMENT PANEL" section for an explanation of the fuel injection system indicator.
- 3. Check the ignition system for intermittent spark.
- Check the idle speed. The correct idle speed is 1050 1250 r/min.



STORAGE PROCEDURE AND MOTORCYCLE CLEANING

STORAGE PROCEDURE	9-2
PROCEDURE FOR RETURNING TO SERVICE	9-3
CORROSION PREVENTION	9-4
MOTORCYCLE CLEANING	9-5
INSPECTION AFTER CLEANING	9-8

STORAGE PROCEDURE AND MOTORCYCLE CLEANING

STORAGE PROCEDURE

If your motorcycle is to be left unused for an extended period of time, it needs special servicing requiring appropriate materials, equipment and skill. For this reason, Suzuki recommends that you trust this maintenance work to your Suzuki dealer. If you wish to service the machine for storage yourself, follow the general guidelines below:

MOTORCYCLE

Clean the entire motorcycle. Place the motorcycle on the side stand on a firm, flat surface where it will not fall over.

FUEL

- Fill the fuel tank to the top with fuel mixed with the amount of gasoline stabilizer recommended by the stabilizer manufacturer.
- 2. Run the engine for a few minutes until the stabilized gasoline fills the fuel injection system.

ENGINE

- Pour one tablespoon of motor oil into each spark plug hole. Reinstall the spark plugs and crank the engine a few times.
- 2. Drain the engine oil thoroughly and refill the crankcase with fresh engine oil all the way up to the filler hole.
- Cover the air cleaner intake and the muffler outlet with oily rags to prevent humidity from entering.

BATTERY

- Remove the battery from the motorcycle by referring to the BATTERY section.
- Clean the outside of the battery with a mild soap and remove corrosion from the terminals and wiring harness.
- 3. Store the battery in a room above freezing.

TIRES

Inflate tires to the normal pressure.

EXTERNAL

- Spray all vinyl and rubber parts with rubber protectant.
- Spray unpainted surfaces with rust preventative.
- Coat painted surfaces with car wax.

MAINTENANCE DURING STORAGE

Once a month, recharge the battery by referring to the BATTERY section. If you cannot charge the battery, consult your authorized Suzuki dealer.

PROCEDURE FOR RETURNING TO SERVICE

- 1. Clean the entire motorcycle.
- Remove the oily rags from the air cleaner intake and muffler outlet.
- 3. Drain all the engine oil. Install a new oil filter and fill the engine with fresh oil as outlined in this manual.
- Remove the spark plugs. Turn the engine a few times. Reinstall the spark plugs.
- 5. Reinstall the battery by referring to the BATTERY section.
- 6. Make sure that the motorcycle is properly lubricated.
- 7. Perform the INSPECTION BEFORE RIDING as listed in this manual.
- 8. Start the motorcycle as outlined in this manual.

CORROSION PREVENTION

It is important to take good care of your motorcycle to protect it from corrosion and keep it looking new for years to come.

Important Information About Corrosion

Common causes of corrosion

- Accumulation of road salt, dirt, moisture, or chemicals in hardto-reach areas.
- Chipping, scratches, and any damage to treated or painted metal surfaces resulting from minor accidents or impacts from stones and gravel.

Road salt, sea air, industrial pollution, and high humidity will all contribute to corrosion.

How to Help Prevent Corrosion

- Wash your motorcycle frequently, at least once a month.
 Keep your motorcycle as clean and dry as possible.
- Remove foreian material deposits. Foreign material such as road salt, chemicals, road oil or tar, tree sap, bird droppings and industrial fallout may damage your motorcycle's finish. Remove these types of deposits as quickly as possible. If these deposits are difficult to wash off, an additional cleaner may be required. Follow manufacturer's the directions when using these special cleaners.
- Repair finish damage as soon as possible. Carefully examine your motorcycle for damage to the painted surfaces. Should you find any chips or scratches in the paint, touch them up immediately to prevent corrosion from starting. If the chips or scratches have gone through to the bare metal, have a Suzuki dealer make the repair.

- Store your motorcycle in a dry, well-ventilated area. If you often wash your motorcycle in the garage or if you frequently park it inside when wet, your garage may be damp. The high humidity may cause or accelerate corrosion. A wet motorcycle may corrode even in a heated garage if the ventilation is poor.
- Cover your motorcycle. Exposure to mid-day sun can cause the colors in paint, plastic parts, and instrument faces to fade. Covering your motorcycle with a high-quality, "breathable" motorcycle cover can help protect the finish from the harmful UV rays in sunlight, and can reduce the amount of dust and air pollution reaching surface. the Your Suzuki dealer can help you select the right cover for your motorcycle.

MOTORCYCLE CLEANING

WASHING THE MOTORCYCLE

When washing the motorcycle, follow the instructions below:

- Remove dirt and mud from the motorcycle with cool running water. You may use a soft sponge or brush. Do not use hard materials which can scratch the paint.
- Wash the entire motorcycle with a mild detergent or car wash soap using a sponge or soft cloth. The sponge or cloth should be frequently soaked in the soap solution.

NOTE: Clean the motorcycle with cool water immediately after riding on road salt or riding along the coast. Be sure to use cool water because warm water can hasten corrosion.

NOTE: Avoid spraying or allowing water to flow over the following places:

- Ignition switch
- Špark plugs
- Fuel tank cap
- Fuel injection system
- Brake master cylinders
- Clutch master cylinder
- Throttle cable boots

NOTICE

High pressure washers such as those found at coin-operated car washes have enough pressure to damage the parts of your motorcycle. It may cause rust, corrosion and increase wear. Parts cleaner can also damage motorcycle parts.

Do not use high pressure washers to clean your motorcycle. Do not use parts cleaner on throttle body and fuel injection sensors.

- Once the dirt has been completely removed, rinse off the detergent with running water.
- After rinsing, wipe off the motorcycle with a wet chamois or cloth and allow it to dry in the shade.
- Check carefully for damage to painted surfaces. If there is any damage, obtain "touch-up" paint and "touch-up" the damage following the procedure below:
 - a. Clean all damaged spots and allow them to dry.
 - b. Stir the paint and "touchup" the damaged spots lightly with a small brush.
 - c. Allow the paint to dry completely.

NOTE: The headlight lens can be fogged after washing the motorcycle or riding in the rain. Headlight fogging will be cleared gradually when the headlight is turned on. When clearing the headlight lens fogging, run the engine to avoid battery discharge.

NOTICE

Cleaning your motorcycle with any alkaline or strong acid cleaner, gasoline, brake fluid, or any other solvent will damage the motorcycle parts.

Clean only with soft cloth and warm water with mild detergent.

PLASTIC PARTS

Plastic parts such as headlight lens, speedometer display, windshield and fairing, are easy to be damaged. When such part is cleaned, wash it using water after cleaning it using neutral detergent or soapy water, and wipe it with a soft cloth.

A WARNING

Do not put anything between the fairing and steering.

If so, it will negatively affect the steering operation.

NOTICE

When any of the following substances is attached to the plastic part such as headlight lens, speedometer display or windshield, it might cause a scratch or damage to the part.

- Wax compound
- Chemical supplies such as oil film removing agent or repellents
- Acidic or alkaline detergent
- Brake fluid, gasoline or organic solvent, etc.

WAXING THE MOTORCYCLE

After washing the motorcycle, waxing and polishing are recommended to further protect and beautify the paint.

- Only use waxes and polishes of good quality.
- When using waxes and polishes, observe the precautions specified by the manufacturers.

SPECIAL CARE FOR MATTE FINISH PAINT

Do not use polishing compounds or waxes that contain polishing compounds on surfaces which have a matte finish. The use of polishing compounds will change the appearance of the matte finish.

Solid type waxes may be difficult to remove from surfaces with a matte finish.

Friction while riding, excessive rubbing or polishing of a surface with a matte finish will change its appearance.

INSPECTION AFTER CLEANING

For extended life of your motorcycle, lubricate it according to the "GENERAL LUBRICATION" section.

WARNING

Operating the motorcycle with wet brakes can be hazardous. Wet brakes may not provide as much stopping power as dry brakes. This could lead to an accident.

Test your brakes after washing the motorcycle, while riding at slow speed. If necessary, apply the brakes several times to let friction dry out the linings.

Follow the procedures in the "INSPECTION BEFORE RIDING" section to check your motorcycle for any problems that may have arisen during your last ride.



CONSUMER INFORMATION

WARRANTIES	10-2
EMISSION CONTROL SYSTEMS	10-3
REPORTING SAFETY DEFECTS	10-4
TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED	10-5
ON-BOARD MOTORCYCLE COMPUTER DATA INFORMATION	10-6
SERIAL NUMBER LOCATION	10-7
LOCATION OF LABELS	10-8

CONSUMER INFORMATION

WARRANTIES

The warranties for your motorcycle are explained in a separate warranty policy booklet given to you at the time of sale. Please read this booklet carefully so you can understand your rights and responsibilities. The following warranties are provided with your motorcycle:

- On-Road Motorcycle Limited Warranty
- Motorcycle Federal Emission Control System Limited Warranty
- California Emission Control System Limited Warranty (Applies ONLY to Suzuki street-legal emission-controlled motorcycles certified for sale and registered in California.)

Suzuki limited warranties and the Federal and California Emission Control System Limited Warranty may not cover damage caused by modifications that would change the original vehicle specifications including, without limitation, modifications of any emission-related parts such as the carburetor(s), fuel injection system components, the engine control module, air suction system components, the catalytic converter (if equipped), evaporative emission control system components, etc.

EMISSION CONTROL SYSTEMS

Your vehicle is subject to U.S. Environmental Protection Agency (EPA) and California Air Resources Board (CARB) emission regulations. These regulations set specific standards for exhaust emission output levels and fuel permeation emissions, as well as particular servicing requirements.

Exhaust Emission Control System

The exhaust emission control system of your vehicle includes a number of parts. While the emission-related parts may vary from model to model, they generally include components of the air induction system, fuel system, ignition system, and exhaust gas recirculation system, as well as devices such as catalytic converters, emission-related sensors, and electronic control units.

Evaporative Emission Control System (if equipped)

The evaporative emission control system of your vehicle consists of the carbon canister, fuel tank, fuel hoses, and fuel vapor hoses. These parts incorporate technologies to control fuel evaporative emissions.

Servicing Requirements

It is essential to have your vehicle serviced according to the maintenance schedule in this manual to maintain good emission performance and to preserve your emission warranty coverage. If parts replacement is necessary, replace the parts with Genuine Suzuki parts or their equivalent. Installing improper replacement parts or performing improper adjustments can cause your vehicle to exceed emission level limits. Tampering emission-related components in a manner which defeats or reduces the effectiveness of these components is prohibited by federal and California law.

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Suzuki Motor of America, Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Suzuki Motor of America, Inc.

To contact NHTSA, you may either call the Vehicle Safety Hot Line toll-free 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Ave., S.E., Washington DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

To contact Suzuki Motor of America, Inc., owners in the continental United States can call toll-free 1-800-444-5077, or write to: Suzuki Motor of America, Inc. Motorcycle Customer Service P.O. Box 1100, Brea, CA 92822-1100.

For owners outside the continental United States, please refer to the distributor's address listed on your Warranty Information brochure.

TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED

Federal law prohibits the following acts or the causing thereof;

- The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

 Removing or puncturing the muffler, baffles, header pipes, screen type spark arrester (if equipped) or any other component which conducts exhaust gases

- Replacing the exhaust system or muffler with a system or muffler not marked with the same model specific code as the code listed on the Motorcycle Noise Emission Control Information label, and certified to appropriate EPA noise standards
- Removing or puncturing the air cleaner case, air cleaner cover, baffles, or any other component which conducts intake air.

Whenever replacing parts on your motorcycle, Suzuki recommends that you use genuine Suzuki replacement parts or their equivalent.

ON-BOARD MOTORCYCLE COMPUTER DATA INFORMATION

Your motorcycle is equipped with on-board computer systems which monitor and control several aspects of motorcycle performance, including the following:


- Emission-related components and engine parameters such as engine speed and throttle position are monitored to provide emission control and to provide optimum fuel economy. Your motorcycle also has an on-board diagnostic system which monitors and records information about emissionrelated malfunctions.
- If your motorcycle is equipped with antilock brakes, conditions such as motorcycle speed and brake performance are monitored, so that the ABS system can provide effective antilock braking.


Some information may be stored by the on-board computer when malfunctions occur. This stored information can assist technicians in repairing the motorcycle. To read the stored information, special equipment is needed and access to the motorcycle or storage device is required. In addition, once Suzuki collects or receives data, Suzuki may use the data for research conducted by Suzuki, make the data available for outside research if need is shown and confidentiality is assured, or make summary data which does not identify specific motorcycles available for outside research.

Others, such as law enforcement personnel, may have access to the special equipment that can read the information if they have access to the motorcycle or storage device.

SERIAL NUMBER LOCATION

You need to know the frame and engine serial numbers to get title documents for your motorcycle. You also need these numbers to help your dealer when you order parts.





The frame number ① is stamped on the steering head as shown in the illustration. The engine serial number ② is stamped on the crankcase assembly.


Write	down	the	serial	numbers
here for	or your	futui	re refer	ence.

Engine No.:		

Frame No.:

LOCATION OF LABELS

Read and follow all of the warnings labeled on your motorcycle. Make sure you understand all of the labels. Keep the labels on your motorcycle. Do not remove them for any reason.



1

WARNING

To reduce the risk of injury:


- Wear a helmet, eye protection, and protective clothing.
- Read owner's manual carefully.

2

$\overline{}$							
COLDTIRE	SOLO RIDING			DUAL RIDING			
PRESSURE	kPa	kgf/cm²	psi	k	Pa	kgf/cm²	psi
FRONT	290	2.90	42	2	90	2.90	42
REAR	290	2.90	42	2	90	2.90	42
FRONT					REAR		
TIRE SIZE		120/70ZR17	'M/C (58\	W)	W) 190/50ZR17M/C (73V		C (73W)
TYPE BRIDGES	BT015F R	ADIAL	M	вт	015R RAD	IAL M	

(3)

The owner's manual contains important safety information and instructions which should be read carefully before operating the vehicle. If the vehicle has been resold, obtain the owner's manual from the previous owner or contact your local SUZUKI dealer for assistance.



(4)

VEHICLE EMISSION CONTROL INFORMATION

SUZUKI MOTOR CORPORATION

ENGINE FAMILY:

EMAJUST EMISSION CONTROL SYSTEM:

ENGINE TUNE-UP SPECIFICATIONS: ALL ADJUSTMENTS ARE TO BE PERFORMED WITH TRANSMISSION IN NEUTRAL

VALVE LASH:

IDLE SPEED:

ENGINE OIL: API SF/SG OR API SH/SJ WITH JASO MA, AND VISCOSITY RATING OF SAE 10W-40

REFER TO YOUR OWNER'S MANUAL FOR ADDITIONAL MAINTENANCE INSTRUCTIONS

THIS VEHICLE COMPOREMS TO U.S. EPA REGULATIONS APPLICABLE TO MODEL YEAR NEW MOTORCYCLES

AND IS CERTIFIED TO HO+NOR NORINE FAMILY EXHAUST EMISSION STANDARD

4 California

VEHICLE EMISSION CONTROL INFORMATION

ENGINE FAMILY:

EVAP FAMILY:

EVAP FAMILY:

EVAHAUST EMISSION CONTROL SYSTEM:

ENGINE TUME-UP SPECIFICATIONS: ALL ADJUSTMENTS ARE TO BE PERFORMED WITH TRANSMISSION IN NEUTRAL

VALVE LASH:

IDLE SPEED:

ENGINE OIL: API SF / SG OR API SH / SJ WITH JASO MA, AND VISCOSITY RATING OF SAE 10W-40

REFER TO YOUR OWNER'S MANUAL FOR ADDITIONAL MAINTEMANCE INSTRUCTIONS

THIS VEHICLE CONFORMS TO U.S. EPA AND CALIFORNIA REGULATIONS APPLICABLE TO MODEL YEAR NEW MOTORCYCLES

AND IS CERTIFIED TO ■ [EPA] AND ■ (CALIFORNIA) g/km HC + NOX ENGINE FAMILY EXHAUST EMISSION STANDARDS

SPECIFICATIONS

DIMENSIONS AND CURB MAS	DIME	NSIONS	AND (CURB	MASS
-------------------------	------	--------	-------	------	------

Overall length	2190 mm (86.2 in
Overall width	735 mm (28.9 in
Overall height	1165 mm (45.9 in
Wheelbase	1480 mm (58.3 in
Ground clearance	120 mm (4.7 in)
Seat height	805 mm (31.7 in
Curb mass	266 kg (586 lbs)

ENGINE

Type	Four-stroke, liquid-cooled, DOHC
Number of cylinders	4
Bore	81.0 mm (3.189 in)
Stroke	65.0 mm (2.559 in)
Displacement	1340 cm3 (81.8 cu. in)
Compression ratio	12.5 : 1
Fuel system	Fuel injection
Air cleaner	Paper element
Starter system	Electric
Lubrication system	Wet sump

DRIVE TRAIN

Clutch		Wet multi-plate type
Transmissio	n	6-speed constant mesh
Gearshift pa	ittern	1-down, 5-up
Primary red	uction ratio	1.596 (83/52)
Gear ratios,	Low	2.615 (34/13)
	2nd	1.937 (31/16)
	3rd	1.526 (29/19)
	4th	1.285 (27/21)
	5th	1.136 (25/22)
	Top	1.043 (24/23)
Final reducti	ion ratio	2.388 (43/18)
Drive chain		RK GB50GSV Z4, 114 links

CHASSIS

Front suspension	Inverted telescopic, coil spring, oil dampedLink type, coil spring, oil damped
Front fork stroke	
Rear wheel travel	140 mm (5.5 in)
Steering angle	30° (right and left)
Caster	23° 25'
Trail	93 mm (3.66 in)
Turning radius	3.3 m (10.8 ft)
Front brake	Disk brake, twin
Rear brake	Disk brake
Front tire size	120/70ZR17M/C (58W), tubeless
Rear tire size	190/50ZR17M/C (73W), tubeless

ELECTRICAL

ELECTRICAL	
Ignition type	.Electronic ignition (Transistorized)
Spark plug	.NGK CR9EIA-9 or DENSO IU27D
Battery	
Generator	.Three-phase A.C. generator
Main fuse	30A
Fuse	15/15/15/10/10/10A
ABS fuse	30A
Headlight	12V 65W (H9) High beam
•	12V 55W (H7) Low beam
Position light	12V 5W × 2
Brake light/Taillight	
Turn signal light	12V 21W
License plate light	12V 5W
Speedometer light	.LED
Tachometer light	.LED
High beam indicator light	.LED
Turn signal indicator light	.LED
Neutral indicator light	.LED
Fuel level indicator light	.LED
Engine coolant temperature indicator light	LED
Oil pressure indicator light	.LED
Fuel injection indicator light	LED
Engine RPM indicator light	
ABS indicator light	
3	
CAPACITIES	
Fuel tank	21.01 (5.5 US gal)
T doi tallit	20.0 L (5.3 US gal) California model
Engine oil, oil change	
With filter change	
Coolant	
000iaiit	. 0.0 = (0.2 00 41)

INDEX

A	D
ACCESSORIES AND	DRIVE CHAIN7-29
LOADING 1-6	
ACCESSORY INSTALLATION	E
GUIDELINES6-2	EMISSION CONTROL
ACCESSORY USE6-2	SYSTEMS10-3
AIR CLEANER7-10	ENGINE COOLANT7-27
	ENGINE COOLANT
В	SOLUTION2-5
BATTERY7-8	
BE EXTRA SAFETY-	INSPECTION7-24
CONSCIOUS ON BAD	ENGINE OIL 2-4,7-18
WEATHER DAYS1-5	_
BE STREET SMART1-7	F
BRAKES7-33	FRONT WHEEL
BREAK-IN4-2	REMOVAL7-42
	FUEL2-2
С	FUEL HOSE7-25
CARRYING A	FUEL SUPPLY CHECK8-2
PASSENGER1-6,5-10	
CATALYTIC	FUSES7-54
CONVERTER7-56	
CLUTCH7-26	G
CONCLUSION 1-7	GEARSHIFT LEVER3-25
CORROSION	
DDEV/ENTION 0-1	

I	M
IF A COLLISION IS IMMINENT,	MAINTENANCE
DO SOMETHING1-3	SCHEDULE7-2
IF YOU DON'T HAVE A HELMET,	MODIFICATION6-5
BUY A HELMET AND WEAR IT	MOST ACCIDENTS CAN BE
EVERY TIME YOU RIDE 1-3	AVOIDED1-2
IGNITION SWITCH3-5	MOTORCYCLE
IGNITION SYSTEM	CLEANING9-5
CHECK8-3	MOTORCYCLE SAFETY
INSPECTION AFTER	FOUNDATION'S
CLEANING9-8	"RIDING TIPS AND PRACTICE
INSPECTION BEFORE	GUIDE" HANDBOOK
RIDING1-6,4-3 INSTRUMENT PANEL3-8	(FOR OWNERS IN USA)1-7
INSTRUMENT PANEL3-6	0
K	ON-BOARD MOTORCYCLE
KEY3-5	COMPUTER DATA
KNOW YOUR LIMITS1-5	INFORMATION10-6
L	P
 LABELS1-7	PRACTICE AWAY FROM
LEFT HANDLEBAR3-18	TRAFFIC1-5
LIGHT BULB	PROCEDURE FOR RETURNING
REPLACEMENT7-47	TO SERVICE9-3
LOADING GUIDELINES 6-4	
LOADING LIMIT 6-3	
LOCATION OF LABELS 10-8	
LOCATION OF PARTS3-2	

LUBRICATION POINTS......7-7

n	1	
REAR BRAKE PEDAL 3-26 REAR WHEEL	TAMPERING WITH NOISE CONTROL SYSTEM	
REMOVAL7-45		5
REPORTING SAFETY	THROTTLE CABLE	J
DEFECTS10-4	PLAY7-2	1
RIDING ON HILLS5-6	TIRES7-3	
RIGHT HANDLEBAR3-20	TOOLS7-	
THATT HANDLEBATT 5 20	10010	·
S	U	
SEAT LOCK AND HELMET	USING THE	
HOLDERS3-26	TRANSMISSION5-	5
SEAT TAIL COVER3-33		
SERIAL NUMBER	W	
LOCATION10-7	WARRANTIES10-	2
SIDE STAND3-28		
SIDE STAND/IGNITION		
INTERLOCK SYSTEM7-41		
SPARK PLUGS 7-13		
SPECIAL SITUATIONS		
REQUIRE SPECIAL		
CARE 1-4		
STARTING OFF5-4		
STARTING THE ENGINE 5-2		
STEERING DAMPER		
MAINTENANCE7-6		
STOPPING AND PARKING5-7		
STORAGE PROCEDURE9-2		
SUSPENSION		
ADJUSTMENT3-29		